

SORENTO

Features & Functions Guide



GETTING TO KNOW YOUR **SORENTO**

Congratulations on Your New Kia Purchase!

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and — above all — your satisfaction.

Using This Guide

The information contained in this guide is a brief overview that will help you become familiar with the operation and features of your new Kia vehicle. The flipbook format facilitates information access, while the detailed illustrations help to ensure the instructions are easy to follow.

This **Features & Functions Guide**, and the specific operational and safety information it provides, is not a substitute for your Owner's Manual. In the interest of your safety and that of your family, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read your Owner's Manual in order to fully familiarize yourself with the important information it contains.

While the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes.

www.kia.com

Consumer - Roadside Assistance
1-800-333-4KIA (4542)

See Back Cover for Vehicle Maintenance Schedule

Always check the Owner's Manual for complete operating information and safety warnings.

ESSENTIAL FEATURES

Air Conditioning/Automatic Climate Control*	27
Audio System – Standard Audio System (Type A)*	20
Audio System – Standard Audio System (Type B)*	21
Audio System – UVO eServices System*	22
Audio System – UVO eServices/Premium Navigation*	23
Aux/USB/iPod® Ports, Power Outlets & AC Inverter*	25
Bluetooth® Wireless Technology	16
Cruise Control	18
Advanced Smart Cruise Control (ASCC)*	19
Digital Clock	25
Passenger Airbag Off Indicator	44
Service Mode	7
Smart Key*	37
Tire Pressure Monitoring System (TPMS)	5
Trip Computer/Tripmeter	6
User Settings	7
Windshield/Rear Wipers & Washers	15

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.



VIDEOS & QR CODES	2
INSTRUMENT CLUSTER	
Instrument Cluster Overview	3
Indicators & Warning Lights	4
Tire Pressure Monitoring System (TPMS)	5
Fuel Economy	5
LCD Instrument Cluster Modes	6
Trip Computer / Tripmeter	6
User Settings	7
Service Mode	7
Drive Mode Integrated Control System	8
Active ECO System (ECO Mode)*	8

DRIVER'S PANEL

Electronic Stability Control (ESC)	9
Hill-Start Assist Control (HAC)	9
Instrument Panel Dimmer	9
AC Inverter*	9
Blind Spot Detection (BSD) System*	10
Lane Departure Warning System (LDWS)*	11
Autonomous Emergency Braking (AEB)*	11
Power Windows, Window Lock & Central Door Lock	12
Power Folding Outside Mirrors*	12
Heated Outside Mirrors	12
Automatic Door Lock/Unlock	12
Fuel Door Release Button	12
Reverse Parking Aid Function*	13
Engine Start/Stop Button*	13
Adaptive Front Light System (AFLS)*	14

STEERING WHEEL CONTROLS

Tilt/Telescoping Steering Wheel	14
Paddle Shifters*	14
Headlights & High Beams	14
Turn Signals & Fog Lights*	15
Windshield/Rear Wipers & Washers	15
Bluetooth® Wireless Technology	16
Audio Controls	18
Standard Cruise Control	18
Advanced Smart Cruise Control (ASCC)*	19

AUDIO SYSTEMS

Standard Audio System (Type A)*	20
Standard Audio System (Type B)*	21
UVO eServices System*	22
UVO eServices with Premium Navigation*	23

CENTER PANEL

Surround View Monitor (SVM)*	24
Digital Clock	25
Aux/USB/iPod® Ports, Power Outlets & AC Inverter*	25
Automatic Gear Shift with Sportmatic® Shifting	26
Paddle Shifters*	26
Automatic Climate Control*	27
AWD (All-Wheel Drive) Lock*	27
Manual Climate Control*	29
Electronic Parking Brake (EPB)*	30
Auto Hold*	30
Heated Steering Wheel*	31
Seat Warmers / Ventilated Seats*	31

SEATING

Front Seat Headrest Adjustment	32
Driver Position Memory System*	32
Power Adjustable Driver's Seat*	33
Manual Adjustable Driver's Seat*	33
2nd-Row Folding Seat	34
3rd-Row Seat - Folding*	35
2nd-Row Auto Folding Seat*	35

OTHER KEY FEATURES

Sunvisor	36
Remote Keyless Entry (Folding Key)*	36
Double-Turn Lock/Unlock All	36
Smart Key*	37
Power Liftgate (Tailgate)*	38
HomeLink® with Auto-Dimming Rearview Mirror*	40
Map/Room Lamps	41
Panoramic Sunroof Operation*	41
Back-Up Warning System (Rear Parking Assist System)*	42
Rear-Camera Display	42
Hood Release Lever and Latch	43
Fuel Cap / Malfunction Indicator (Check Engine Light)	43
Child Safety Locks	43

SAFETY FEATURES

Occupant Detection System (ODS) /	
Passenger Airbag Off Indicator	44
Seat Belts	44
Seat Belt Retractor Locks	44

NORMAL MAINTENANCE SCHEDULE

LEGAL DISCLAIMERS . . . See Back Inside Cover Page

Kia provides a number of video resources at your disposal to assist you with becoming familiar with the features and functions found in your Kia vehicle. You can access these resources by snapping the QR Codes with your smartphone/tablet (mobile devices) or by visiting the following website: www.KuTechVideos.com/um13/2017. Continue reading for a more in-depth look at QR Codes and for instructions on how to use them.

What are QR Codes?

A QR Code is a square, 2-dimensional barcode that can be read by mobile devices loaded with an appropriate barcode or QR Code Reader App. The app reads the barcode image and then launches/uploads the specific information the code contains, such as URLs, text, photos, videos and so much more.

How to Use QR Codes

If you have a mobile device with a QR Code Reader App, you can snap the code with your phone and you'll be provided a video with additional information pertaining to the topic. For example, in the Fuel Cap section, if you would like additional information, just snap the code with your mobile device to view the selected Kia Features & Functions Video.

How to snap a QR Code

1. With your mobile device, download a QR Code Reader App. With many devices, you can do this through an app store or marketplace
2. Open the QR Code Reader App on your mobile device
3. The app will utilize your device's camera. Center the code in the camera viewing area:
 - With some apps, as soon as the app recognizes the code, it will launch the corresponding video
 - With other apps, you will have to snap or take a picture of the code. The app will then launch the corresponding video
 - For operation specifics, refer to the instructions that come with the QR Code Reader App

QR CODE

One-Click Fuel Cap Video

To view a video on your mobile device, snap this QR Code or visit the listed website.



www.KuTechVideos.com/um13/2017


REMINDER: When accessing videos on your mobile device, standard cellular data rates may apply.

QUICK TIPS

1. If you're having trouble scanning codes, check the following:
 - The code should be centered and focused in your mobile device's camera screen
 - Consider moving your device closer to or farther away from the code
 - The code should be well lit, without significant shadow
 - Avoid scanning from a significant angle
 - Confirm that the device's app supports 2D QR Code scanning.
 - Try another QR Code Reader App; not all apps are created equal
2. After scanning, if a "connecting" message appears and then nothing happens or there's a "connection error" message, this typically indicates that your device is having trouble connecting to the Internet
3. When accessing videos on your mobile device, standard cellular data rates will apply

Instrument Cluster Overview


- A** Tachometer
- B** Turn Signal Indicators
- C** Speedometer
- D** Engine Temperature Gauge
- E** Indicators & Warning Lights
- F** Gear Shift Position Indicator
- G** Odometer/Trip Computer/Tripmeter
- H** Fuel Gauge



(Type A Cluster)

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster and the function of all indicator and warning lights, please refer to the Owner's Manual.

Indicators & Warning Lights





(Type B Cluster)


Your vehicle's instrument cluster and indicator light locations may differ from those in the illustrations. For more information on the instrument cluster and the function of all indicator and warning lights, please refer to the Owner's Manual.


- | | | | | | |
|--|---|--|--|--|--|
| | Engine Oil Pressure Warning Light | | All-Wheel Drive (AWD) Warning Light* | | Anti-Lock Braking System (ABS) Warning Light |
| | Malfunction Indicator Light | | All-Wheel Drive (AWD) Lock Indicator Light* | | Electronic Stability Control (ESC) OFF Indicator Light |
| | Electric Parking Brake (EPB) Warning Light* | | Electronic Power Steering (EPS) Warning Light | | Electronic Stability Control (ESC) Warning Indicator Light |
| | Seat Belt Warning Light | | Charging System Warning Light | | AUTO HOLD Indicator* |
| | Light ON Indicator Light | | Airbag Warning Light | | SET Cruise Control SET Indicator* |
| | Head Lamp ON Indicator Light | | Low Fuel Level Warning Light | | CRUISE Cruise Control ON Indicator* |
| | High Beam Indicator Light | | Immobilizer Indicator Light* | | Washer Fluid Warning Light* |
| | Front Fog Light Indicator Light | | Engine Coolant Temperature Warning Light | | Master Warning Light |
| | High Beam Assist Indicator Light* | | Icy Road Warning Indicator Light | | Electronic Brake Force Distribution (EBD) System Warning Light |
| | Parking Brake & Brake Fluid Warning Light | | Low Tire Pressure Light / Tire Pressure Monitoring System (TPMS) Malfunction Indicator Light | | Lane Departure Warning System (LDWS) ON/OFF Indicator Light |
| | Autonomous Emergency Braking (AEB)* | | | | |


Tire Pressure Monitoring System (TPMS)

The TPMS indicator  functions as both Low Tire Pressure Light and TPMS Malfunction Indicator.

The indicator  will illuminate if one or more tires is significantly underinflated, or if a spare tire has been installed that does not have a TPMS device or when the outside temperature drops considerably.



Inflate tire(s) to specifications using an accurate digital tire pressure gauge to turn off Low Tire Pressure Indicator . See front driver's door jamb for PSI specification. The Low Tire Pressure Position Indicator **A** is displayed on the LCD screen in the Instrument Cluster when the tire(s) are underinflated.

When there is a problem with the TPMS, the TPMS Malfunction Indicator  will blink for approximately one minute and then illuminate. See dealer for service.

Fuel Economy

There are several factors that contribute to your vehicle's fuel economy, including maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics. Below are tips on how to help improve fuel economy:

- Keep your vehicle in good condition with regular maintenance
- Don't let the engine idle longer than necessary
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicles
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

REMINDER: Driving range varies depending on a vehicle's fuel tank size, (e.g., 12-gal. vs. 24-gal). Even though the two vehicles MPG may be the same, the vehicle with the larger tank will have the greater range.

For more information on Fuel Economy, you can snap the QR code above to view a video or refer to the brochure "GETTING MORE OUT OF EVERY GALLON, FUEL-SAVING TIPS TO DRIVE BY" available at your local dealership.

QUICK TIPS

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on "cold tires"
- For proper maintenance and optimal fuel economy, maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- In winter or cold weather, the TPMS light may illuminate if the tire pressure was adjusted to the recommended tire inflation pressure during warm weather

REMINDER: Consult your dealer for service if Low Tire Pressure Light remains illuminated after inflating your tire(s).

QR CODES

To view these videos on your mobile device, snap these QR codes or visit the listed website.

Refer to page 2 for more information.

Tire Pressure Monitoring System Video



www.KuTechVideos.com/um13/2017

Fuel Economy Video



www.KuTechVideos.com/um13/2017

LCD Instrument Cluster Modes

Press the Mode button **A** to cycle through different LCD Instrument Cluster Modes:



Trip Computer Mode: Displays driving information for tripmeter, fuel economy, etc.



Turn-by-Turn Mode*: Displays the state of the navigation system



Smart Cruise Control (SCC) / Lane Departure Warning System (LDWS)*: Displays the state of the SCC and LDWS



A/V Mode: Displays the state of the A/V System




Information Modes: Informs on service intervals and pressure status of each tire



User Settings Mode: Change settings of the doors, lamps and other features

Your vehicle's steering wheel buttons may differ from those in the illustrations.


Trip Computer / Tripmeter



(Controls located on Steering Wheel)

The Trip Computer is a driver information system that displays information related to driving on the display when the ENGINE START/STOP button is in the ON position.


To cycle through the LCD Instrument Cluster modes, press the Mode button **A**.

To select and enter Trip Computer mode , roll the Scroll button **B** up/down and then press to enter. To cycle through and select the different screens (Fuel Economy, Trip A, Trip B), roll the OK button **B** up/down again and then press enter. When displaying TRIP A or TRIP B screens, press and hold the OK button **B** to reset the Tripmeter to zero.


Press the OK button **C** to go back to the previous mode/item

REMINDERS:

- Appearance of Tripmeter display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected



User Settings

To enter the User Settings mode in the LCD Instrument Cluster Modes, press the Mode button **A** when the vehicle is at a standstill and with the ENGINE START/ STOP button in the ON position and select User Settings  by pressing the OK button **B**.

You can navigate the selections on the display by rolling the OK button **B**, and then selecting the item by pressing the OK button **B**.

Press the Return button **C** to go back to the previous mode/item

User Settings mode:

Driving Assist

- Smart Cruise Control Response*
- Rear Cross Traffic Alert*
- Forward Collision Warning*

Door/Liftgate (Tailgate)

- Automatically Lock/Unlock
- Two Press Unlock
- Door Lock Sound
- Power Liftgate*
- Smart Liftgate*

Lights

- One-Touch Turn Signal
- Head Lamp Delay*
- Welcome Light*

Sound

- Park Assist System Volume*
- Blind Spot Detection Sound*
- Welcome Sound*

Seat/Steering

- Easy Seat Access*
- Steering Position


Service Interval

- ON/OFF
- Set mileage/months

Other Features

- Fuel Economy Auto Reset ON/OFF
- Wiper/Lights Display*
- Fuel Economy Unit
- Speedometer Subscale*
- Temperature Unit
- Tire Pressure Unit
- Language

Service Mode

To enter Service Mode, press the Mode button **A**, scroll to Service Mode  by rolling the OK button **B**. Then press the OK button **B** to enter. System will display number of miles remaining until next service is due, as well as the type of service due.

When service is required, the following will be displayed:

Service Required **D**.

To reset the Service Mode system, press and hold the OK button **B** for more than 1 second.



Press the Return button **C** to go back to the previous mode/item

To turn **Service In OFF** **E**, go to User Settings.

Service Interval Setting **F**

To set the service interval in User Settings mode:

- Press the Mode button **A** to cycle to User Settings and press the OK button **B** to enter
- If Service Interval is OFF, press the OK button **B** to turn ON
- Roll the OK button **B** to select/change the interval setting
- Press the OK button **B** to select the interval



(Type B cluster)

QR CODES

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to page 2 for more information.

LCD Display: Maintenance Video



www.KuTechVideos.com/um13/2017

LCD Display Video



www.KuTechVideos.com/um13/2017



Drive Mode Integrated Control System

The Drive Mode may be selected depending on driver's preferences and road conditions.

To cycle through the different Drive Modes **A**, press the DRIVE MODE button **B**. The Instrument Cluster will display COMFORT or ECO when selected. When in Normal mode, it will not display in the Instrument Cluster.

REMINDERS:

- The system is turned ON and in Normal mode when ignition is in the ON position
- When ECO mode is selected, the indicator will display and system remains on, even when ignition is cycled
- Steering effort may be slightly increased in Sport mode



(Located on Center Panel below Gear Shift)*

Active ECO System (ECO Mode)*

The Active ECO system helps improve fuel economy by controlling several vehicle components. When activated, it optimizes drivetrain operations such as engine power and transmission to help improve fuel economy.

To turn ON, press the DRIVE MODE button **B**. The ECO mode indicator in the instrument cluster will illuminate, indicating that the vehicle is in ECO mode and Active ECO is operating. The Active ECO system will remain on even when the ignition is cycled.

To turn the Active ECO system OFF, press the DRIVE MODE button **B** again.

QUICK TIPS

To help improve your fuel economy:

- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Be sure the wheels are properly aligned

For more information on Active ECO, refer to your Owner's Manual or contact your local dealership.

QR CODE

Active ECO System Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017


Electronic Stability Control (ESC)

The ESC system is designed to help stabilize the vehicle during cornering maneuvers. It is a good idea to keep the ESC turned on for daily driving whenever possible.

Press ESC OFF button **A** to turn Traction Control OFF/ON.

To turn OFF both the Traction Control and Stability Control, press and hold for more than 3 seconds. Press again to turn ON.

REMINDERS:

- ESC is active by default at vehicle start-up. When ignition is cycled, ESC will turn ON again
- The ESC Indicator Light  in the instrument cluster will illuminate whenever the ESC is in operation

For more information on Electronic Stability Control (ESC) and its specific features and operations, please refer to your Owner's Manual.


Hill-Start Assist Control (HAC)

HAC helps prevent the vehicle from rolling backwards when accelerating from a stop while on a steep incline. The HAC automatically activates whether the ESC is OFF or ON but does NOT activate when the ESC has malfunctioned.

REMINDER: The HAC does not operate when the gear shift is in the P (Park) or the N (Neutral) position.

QUICK TIPS

- When HAC is active (e.g., during initial acceleration from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator – this is normal HAC operation.
- HAC provides a 2-second delay before the vehicle may start rolling backwards



(Button panel located left of Steering Wheel)


Instrument Panel Dimmer

With parking lights/headlights ON, press button **B** (+) or (-) to adjust the brightness of the instrument panel illumination.

REMINDERS: The Instrument Panel Dimmer does not adjust brightness on the UVO eServices nor the UVO eServices with Navigation system screens. Use those system's settings to adjust brightness on the screens.

AC Inverter*

The AC Inverter supplies 115V/150W electrical power to operate accessories or equipment. Press AC Inverter button **C** to activate.




(Outlet located on back of Center Console*)

Blind Spot Detection (BSD) System*

The BSD system uses radar sensors to help alert the driver before changing lanes. The light on the BSD button **A** will illuminate when turned ON. The outside rearview mirror warning lights will also illuminate for 3 seconds.

The system will become active when the vehicle is traveling more than 18 mph and will alert the driver if another vehicle is detected by the radar sensor.



(Button panel located left of Steering Wheel)

Blind Spot Detection (BSD) / Lane Change Assist (LCA)

1st-stage alert: When another vehicle is detected within the BSD System boundary **B**, or vehicle in the LCA boundary **C** approaches at a high speed, a yellow indicator will illuminate on the outside rearview mirrors.

2nd-stage alert: When 1st-stage alert is on and the driver activates a turn signal, a flashing yellow indicator will illuminate on the outside rearview mirrors and the system will sound an alert.

RCTA (Rear Cross Traffic Alert)

If the RCTA system sensors detect approaching vehicles from the left or right side **D**, the system will sound an audible alert, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the LCD screen, when these conditions are met:

- The gear shift is in Reverse
- The vehicle moves in reverse
- The vehicle is moving less than 6 mph
- The RCTA can be set to on/off in User Settings from the LCD Instrument Cluster modes

REMINDERS:

- When the BSD is ON and the vehicle power is cycled to OFF then ON again, the BSD system returns to ON
- The RCTA feature can be turned OFF/ON in User Settings. When vehicle power is cycled, the RCTA will remain in the previous state

QR CODE

Blind Spot Detection System w/RCTA Video

To view a video on your mobile device, snap this QR Code or visit the listed website.


Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

For more information on the above systems, please refer to the Owner's Manual.

Lane Departure Warning System (LDWS)*


With the ENGINE START/STOP button in the ON position, press the LDWS button **D** to turn system ON. The instrument cluster indicator  will illuminate.

If the LDWS detects that you are veering outside of your lane, the system may issue a warning on the LCD screen and an alert may sound, under these conditions:


- The vehicle exceeds approximately 37 mph
- The LDWS system recognizes the lane the vehicle is traveling in
- LDWS will stay on when the ignition is cycled

REMINDER: LDWS will not issue a warning if the turn signal is activated.


The Lane Departure Warning System (LDWS) is not a substitute for safe and proper driving. Always drive safely and use caution. LDWS may not always alert the driver if the vehicle is driven outside of its lane.




When the LDWS sensor detects the lane traveling in, both lanes are illuminated



When the LDWS sensor does not detect the lane traveling in, the lanes are not illuminated



When the LDWS sensor detects the vehicle veering outside of the lane traveling in, a yellow indicator will illuminate either on the left or right lane (shown in both images above)



QR CODE

Lane Departure Warning System Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

Autonomous (Assist) Emergency Braking (AEB)/Forward Collision Warning (FCW)*

The AEB helps to alert the driver when rapidly approaching a vehicle that is slowing down, braking or stopped **A**. A warning message will appear on the LCD screen and a chime will sound. The AEB will become active when the vehicle is traveling more than 6 mph.

To turn the AEB off, go to User Settings in the LCD Instrument Cluster modes.

REMINDER: The AEB will be activated by default when vehicle power is cycled on, even when previously set to off

Autonomous (Assist) Emergency Braking is not a substitute for safe driving, and may not detect all objects in front of vehicle. Always drive safely and use caution.



Power Windows, Window Lock & Central Door Lock

A Pull/Press to operate Front Windows Auto Up/Down*

B Press to Unlock/Lock All Doors

C Press to disable Rear Passenger Windows

REMINDER: When pressed **C** window controls for the Rear Passenger Windows are disabled.

Power Folding Outside Mirrors*

Press the L or R buttons **D** to select the mirror to adjust.

Press button arrows **E** left/right or up/down to adjust mirror position.

Toggle button **F** left/right to unfold/fold the outside rearview mirrors.

Toggle button **F** to center to automatically fold/unfold mirrors when:

- The Smart Key* Lock/Unlock buttons are pressed
- The door outside handle button* is pressed


QUICK TIP

The mirrors will automatically unfold when the Smart Key* is within close proximity to the vehicle.

REMINDER: To lock position of mirrors, press switch to the OFF position (LED not lit).

Heated Outside Mirrors

Mirror heaters are controlled with Rear Defroster.




(Button/switch panel located on Driver's Door)

Automatic Door Lock/Unlock

Auto Door Lock/Unlock will engage when the gear shift is moved in-to or out of the P (Park) position. Refer to the User Settings in the LCD Instrument Cluster modes on how to turn Auto Door Lock/Unlock ON/OFF.

Fuel Door Release Button

Press the Fuel Door Release button to release the fuel door.



(Button located left of Steering Wheel)

Reverse Parking Aid Function*


When the gear shift lever is moved into R (Reverse) and while the vehicle is moving backward, the outside rearview mirrors **A** will rotate downward to aid in reverse parking.

When the left or right mirror buttons **B** are depressed, the Reverse Parking Aid Function will operate (LED lit).

To turn OFF the function, press the switches again.

The outside rearview mirrors will automatically return to their original positions when:

- The ENGINE START/STOP Button is in the OFF position
- The gear shift lever is moved to any position except R (Reverse)
- Outside rearview mirror switches are not depressed




(Button/switch panel located on Driver's Door)

REMINDER: When one of the outside rearview mirror switches are not depressed (LED lit), the Reverse Parking Aid Function will not operate and the outside rearview mirrors will not rotate downward.

Engine Start/Stop Button*

To start the engine:

1. Depress the brake pedal
2. Press the ENGINE START/STOP button while gear shift is in P (Park)



To turn the engine OFF: Press the ENGINE START/STOP button.

To use the ENGINE START/STOP button, you must have the Smart Key fob on your person or inside the vehicle.

REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the engine off and to the ACC position by pressing the ENGINE START/STOP button for more than 2 seconds or 3 times successively within 3 seconds
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the ENGINE START/STOP button (Lock button side closest) and press to start engine

QUICK TIPS

To use electrical accessories:

ACC position

- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button once (orange light)

ON position

- When already in the ACC position (orange light) and without depressing the brake pedal, press the ENGINE START/STOP button again (red light)
- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button twice (red light)

Keeping the vehicle in ACC or the ON position for extended periods of time without turning engine on may discharge the vehicle's battery.

QR CODE

Engine Start/Stop Button & Smart Key Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.




www.KuTechVideos.com/um13/2017

Tilt/Telescoping Steering Wheel

To adjust the Steering Wheel, press the Lock-Release Lever **A** down and adjust the desired angle **B** and distance **C**.

When finished, pull the Lock-Release Lever **A** up to lock Steering Wheel in place.




QUICK TIP


It may be helpful to pull/push bottom of Steering Wheel towards/away from you to adjust desired distance.

Headlights & High Beams

To operate:

- Rotate switch to change the Headlight function
- Push lever to turn High Beams ON
- Pull lever to flash Headlights/High Beams

-  Headlight position
-  Parking light position
- AUTO Automatic Headlights position
- OFF OFF position



AUTO Light function* — When the light switch is in the AUTO Light position, the tail lights and headlights will turn ON/OFF automatically depending on the amount of light outside the vehicle.

Adaptive Front Lighting System (AFLS)*

The Adaptive Front Lighting System helps improve visibility during nighttime driving by aiming the low beam headlights in the direction the vehicle is moving. AFLS controls the aiming direction based on steering angle and speed.

When the light switch is in the AUTO Light position, the AFLS will activate.

REMINDER: When the AFLS indicator illuminates on the instrument cluster, the AFLS is not working properly. See authorized Kia dealer for service.

Turn Signals & Fog Lights*

To operate:


- Turn Signals - Move lever Up/Down for Right/Left Turn Signal
- Fog Lights - Push toggle switch to turn Fog Lights ON/OFF

REMINDER: Headlights must be ON for Fog Light operation.

One-Touch Lane Change Signal is activated by moving the Turn Signal Lever up/down slightly for less than 1 second and then releasing. The lane change signal will blink 3 times.

To change how many times (3/5/7) the Lane Change Signal blinks, go to User Settings Mode in the LCD Instrument Cluster modes.


For more information on the User Settings Mode, please refer to your Owner's Manual.



Windshield Wipers & Washers

To operate:

- Move lever Up/Down to change Wiper modes
- Push switch **A** to adjust Intermittent Wipe
- Pull lever to spray and wipe



MIST: Single wipe

OFF: Wiper off

INT: Intermittent Wipe

LO: Slow wipe

HI: Fast wipe


QUICK TIP

Moving switch (A) up increases intermittent wipe frequency and wipe speed. Moving switch down decreases frequency of wipes.

Rear Wiper & Washer

To operate:

- Rotate Rear Wiper switch to change Wiper modes
- Push to spray and wipe



HI: Fast wipe


LO: Slow wipe

OFF: Wiper off

QUICK TIP

On Rear Wipers, intermittent wipe function is not adjustable.

Bluetooth® Wireless Technology



A Talk button: Press to activate voice recognition/bring up menus/place calls with minimal voice command prompts from the system

B Volume button: Roll up/down to raise/lower speaker volume

C Mute button: Press to mute the volume during a call

QUICK TIP

When using the voice command feature, wait for the system BEEP before speaking the command.

D Receive/Place Call button: Press to receive/place/transfer calls. Press to place a call using voice command prompts from the system, or to answer an incoming call

E End Call button: Press to end a call or cancel a function

QUICK TIPS

- Phonebook transfer upload time varies by phone model and with number of phonebook entries
- Because of differences in phone quality, service providers and **Bluetooth®** Wireless Technology chip programming, functionality may differ from one phone to another
- Changing language setting may delete paired phones

Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

For more information, if equipped, refer to the Car Multimedia System User's Manual or the UVO System User's Manual. For Bluetooth® Wireless Technology FAQs, go to www.kia.com, Owners section, or call Consumer Information for Bluetooth® Technology at (800) 333-4KIA. Refer to your Owner's Manual for more specific Bluetooth® Wireless Technology phone pairing and operation instructions.

Bluetooth® Wireless Technology

Pairing a Phone

For instructions on how to pair a phone, refer to the audio system's user's guide or your vehicle's Quick Start Guide.

QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for phonebook download and to allow acceptance of all future **Bluetooth®** connection requests

How to Place a Call

When using the voice command feature, wait for the system BEEP before speaking the command.

There are two options for placing a call:

Standard Audio Systems*

- Option 1: Press the Receive/Place Call button **D** (system will prompt you through call process)
- Option 2: Press the Talk button **A** (system will BEEP to indicate it is ready for call placement). Then say the command "Call {name}" or "Dial {number}"

UVO eServices and UVO eServices with Premium Navigation*

- Option 1: Press the Receive/Place Call button **D** (displays the phone screen with number keypad)
- Option 2: Press the Talk button **A**. Then say the command "Call {name}" or "Dial {number}"

Voice Recognition and Phone Contact Tips

The Kia Voice Recognition System may have difficulty understanding some accents or uncommon names. When using Voice Recognition to place a call, speak in a moderate tone, with clear pronunciation.

Help your **Bluetooth®** Wireless Technology Voice Recognition performance by making a few simple changes to your phone contacts:

- Use full names vs. short or single-syllable names ("John Smith" vs. "Dad"; "Smith Residence" vs. "Home")
- Avoid using special characters or hyphens (@, &, #, /, -, *, +, etc.)
- Avoid using acronyms ("In Case of Emergency" vs. "ICE")
- Spell words completely, no abbreviations ("Doctor Goodman" vs. "Dr. Goodman")

QR CODE

Voice Recognition Tips Video


To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

Audio Controls



A Audio Mode button: Press to cycle through FM/AM/SiriusXM® Media (CD, USB, iPod®, Aux, *Bluetooth*® Audio, My Music) modes

B Seek/Presets buttons:

FM/AM/SiriusXM® Modes: Press to advance through Preset Stations. Press and hold to auto seek

Media Modes: Press up/down to move track up/down. Press and hold to fast forward/rewind

C Volume buttons: Roll up/down to raise/lower volume

D Mute button: Press to mute all audio

QUICK TIP

Pressing the Audio Mode button for more than 1 second will turn Audio Mode ON/OFF.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Standard Cruise Control

E CRUISE Control ON/OFF button: Press to turn the Cruise Control ON/OFF

F Resume Cruising Speed button: Press up to resume or increase cruising speed

F Set Cruising Speed button: Press down to set or decrease Cruising Speed

G Cruise Control CANCEL button: To cancel Cruise Control, do one of the following:

- Press the brake pedal
- Press the CANCEL button **G**

QUICK TIPS

- Cruise Control is designed to function above 25 mph
- The Cruise Control system will not activate until the brake pedal has been depressed at least once after ignition ON or engine start

REMINDER: Standard Cruise Control is a part of the Advanced Smart Cruise Control (ASCC)* and can be set as the operating mode. To switch from ASCC to Standard Cruise Control, press and hold the CRUISE button (the ASCC system must not be activated to change modes). Repeat to switch back to ASCC mode.

Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details

Advanced Smart Cruise Control (ASCC)*

The Advanced Smart Cruise Control (ASCC)* system allows you to set the vehicle to maintain a speed so long as it is not limited by traffic. When traffic is encountered, the vehicle will be slowed to maintain a set distance behind traffic without depressing the accelerator or brake pedal.

To set/adjust the ASCC speed:

- Push the CRUISE button **A** to turn system ON. The CRUISE indicator will illuminate on the instrument cluster
- Accelerate/decelerate to the desired speed and press lever **B** down to set speed
- Press the ASCC lever **B** up or down to adjust or set speed

To set the vehicle-to-vehicle distance, press the ASCC button **C** on the steering wheel. The image on the LCD screen **E** will change when scrolling through the settings.

The CANCEL button **D** will disable Cruise Control and the display **F** will show "Smart Cruise Control canceled". To resume at the previously set speed, press the Resume button **B**.

REMINDERS:

- Cruise Control button must be ON in order to turn ASCC ON/OFF
- ASCC mode is automatically activated by default when ignition is turned on and cycled


QUICK TIPS

To change the Cruise Control mode from ASCC **G** to standard Cruise Control **H**, press and hold button **C**. Repeat to switch modes again (The ASCC system must not be activated to change modes).


For the ASCC System to operate:

- When no vehicle is in front, you must be travelling at a minimum speed of 20 mph
- When following a vehicle, there is no minimum speed requirement

When following a vehicle, the system will automatically adjust the cruise speed based on the vehicle in front. It may bring the vehicle to a complete stop if necessary. If the vehicle stops for more than 3 seconds, the accelerator pedal must be depressed or press lever **B** up or down to start driving.



(Buttons located on right side of Steering Wheel)



QR CODE


Advanced Smart Cruise Control Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.




www.KuTechVideos.com/um13/2017



Standard Audio System (Type A)*

FM/AM/SiriusXM®/Media (CD, USB, iPod®, Aux, *Bluetooth*® Audio, My Music)*



QR CODE

Standard Audio System Videos

To view these videos on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/audio/base_system

Your vehicle's audio system may differ from that in the illustration. For further audio system operations, refer to pages 21-23 or see your Owner's Manual.

Audio System Setup Options


Press the SETUP button, then use the TUNE knob to cycle through the available settings for each equipped audio option. Press the TUNE knob to adjust the audio option selected. Audio options may include the following:

- **Display settings** – Mode Popup, Text Scroll, Media Display
- **Sound settings** – Sound Settings, Speed-Dependent Volume, Voice Recognition Volume
- **Phone settings** – Pair Phone, Phone List, Contacts Download, Auto Download, Audio Streaming, Outgoing Volume, *Bluetooth*® System off
- **System settings** – Memory Information, Prompt Feedback, Language

Sound Settings – To adjust the sound settings (bass, middle, treble, fader, balance), select Sound settings in the SETUP menu. Then use the TUNE knob to cycle to the selection and press the TUNE knob to select. Turn the TUNE knob left/right to adjust sound setting.

Standard Audio System (Type B)*


FM/AM/SiriusXM®/Media (CD, USB, iPod®, Aux, Bluetooth® Audio, My Music)*



Audio System Setup Options

Press the SETUP key, then using the touchscreen, press the menu item to enter (Display, Sound, Clock/Calendar, Phone, System). Adjust the available settings for each equipped audio system setup option by pressing the onscreen buttons/arrows. Audio system setup options may include the following:


- **Display settings** – Adjusting the Brightness, Mode Popup, MP3 Information Display
- **Sound settings** – Sound Settings, Speed Dependent Volume Control, Voice Recognition Volume, Touchscreen Beep
- **Clock/Calendar settings** – Clock Settings, Time Format, Calendar Settings, Clock Display
- **System settings** – Memory Information, Prompt Feedback, Language

Sound Settings – When in the SETUP menu, select Sound and then Sound Setting. Adjust the settings by pressing the onscreen arrows and then return  to exit.

Your vehicle's audio system may differ from that in the illustration. For further audio system operations, refer to pages 21-23 or see your Owner's Manual.

UVO eServices System*

FM/AM/SiriusXM®/Media (MP3, USB, iPod®, Jukebox, Aux, *Bluetooth*® Audio)



Your vehicle's audio system may differ from that in the illustration. For further UVO eServices System operations, refer to the UVO System User's Manual. See your Owner's Manual for other details.

UVO eServices Registration/Activation – To use UVO eServices:

1. Register through your UVO eServices app or at MyUVO.com
2. On your Smartphone, go to an app store or marketplace to download the UVO eServices app and log in to the app using your MyUVO.com account credentials
3. Follow the app's phone pairing and activation steps

Sound Settings

To adjust the sound settings (bass, middle, treble, fader, balance):

1. Select the on-screen SOUND button on the audio mode display
2. Then press the on-screen CHANGE button of the selection (FADER/BALANCE, TONE). To adjust, press the on-screen arrows.

Android Auto*

Setting up Android Auto

1. From an Android Auto compatible device, download the Android Auto app from the Google Play™ Store
2. Open the Android Auto app and proceed with the on-screen instructions to complete setup on the mobile device.

How to start Android Auto

1. Press the SETUP hard key
2. Press the Connectivity icon
3. Check the box for Android Auto to enable Android Auto
4. Connect the Android™ device with the vehicle using a factory USB cable
5. From the vehicle's home screen, press the Android Auto icon to launch Android Auto


QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- Only MP3 or WMA files may be played or copied to Jukebox

- At any time, you can interrupt UVO eServices System Command Feedback by pressing the TALK button on the steering wheel
- Prolonged use of the UVO eServices system in ACC mode may drain the vehicle's battery

UVO eServices with Premium Navigation*

FM/AM/SiriusXM®/Media (Disc, USB, iPod®, Aux, Bluetooth® Audio, My Music)



UVO eServices Registration/Activation - To use UVO eServices:

1. Register through your UVO eServices App or at MyUVO.com
2. On your Smartphone, go to an app store or marketplace to download the UVO eServices App and log in to the app using your MyUVO.com account credentials.
3. Follow the Apps phone pairing and activation steps

Sound Settings

To adjust the sound settings - Fader/Balance, Tone, Touch-Screen Beep ON/OFF and Speed-Dependent Volume Control ON/OFF - from any audio mode:

4. Press the SETUP button on the Audio Control Unit
5. Select the on-screen SOUND button
6. Select the menu item to change settings
7. Use the on-screen buttons to adjust settings
8. Press the return button to save settings

Android Auto*

Setting up Android Auto

1. From an Android Auto compatible device, download the Android Auto app from the Google Play™ Store
2. Open the Android Auto app and proceed with the on-screen instructions to complete setup on the mobile device.

How to start Android Auto

1. Press the SETUP hard key
2. Press the Connectivity icon
3. Check the box for Android Auto to enable Android Auto
4. Connect the Android™ device with the vehicle using a factory USB cable
5. From the vehicle's home screen, press the Android Auto icon to launch Android Auto

QR CODE

UVO eServices with Premium Navigation System Videos

To view these videos on your mobile device, snap this QR Code or visit the listed website. Refer to page 2 for more information.



www.KuTechVideos.com/audio/avn4

Your vehicle's audio system may differ from that in the illustration. For further UVO eServices with Premium Navigation System operations, refer to the Car Multimedia System User's Manual. For other audio system information, see page 20-22.

QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- Prolonged use of the UVO eServices with Premium Navigation system in ACC mode may drain the vehicle's battery. A warning screen may appear periodically to remind users that the navigation system should be operated when the engine is running to prevent battery discharge

Surround View Monitor (SVM)*


The Surround View Monitor (SVM) is a parking support system that shows the areas around the front, rear, left, and right sides of the vehicle via four cameras displayed in the navigation screen.

Front SVM operation:


- The camera view will display on the navigation screen in both Drive and Neutral
- In Drive, the camera view will continue to display until the vehicle is above approximately 13 mph
- The camera view will reappear on the navigation screen whenever the vehicle drops below approximately 13 mph

The Front SVM camera is ON when:

1. The ENGINE START/STOP button is ON
2. The gear shift is in Drive or Neutral
3. The SVM button **A** is pressed ON



(Located next to gear shift)



QUICK TIP

The Front SVM camera will turn off when the gear shift is moved into Park or Reverse or the SVM button is pressed.

Rear SVM operation:

- The camera view will automatically display on the navigation screen when the vehicle is shifted into Reverse
- The camera view will turn off when the vehicle is shifted out of Reverse

Camera View Modes – To change camera view modes, press the icons shown below on the navigation screen to select the mode.

Front SVM - when in Drive & Neutral:

- Displays the front side and SVM images simultaneously on the screen
- Displays the front side image on the screen
- Displays the front side and left side images simultaneously on the screen
- Displays the front side and right side images simultaneously on the screen

Rear SVM - when in Reverse:

- Displays the rear view and SVM images simultaneously on the screen
- Displays the rear side image on the screen
- Displays the rear and left side images simultaneously on the screen
- Displays the rear and right side images simultaneously on the screen

QR CODE

Surround View Monitor Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

REMINDER: The SVM camera is equipped with an optical lens to provide a wider range of vision and may appear different from the actual distance.

The Surround View Monitor system is only a supplemental device. Drivers should not rely solely on the SVM information when parking and backing up. Drivers should always pay attention and directly check the left/right and rear.

Digital Clock

Standard Audio System*:

Press SETUP button on audio system, then press on-screen instructions to change clock settings.

UVO eServices System Clock Setup*:

Press the SETUP button, then press the on-screen Clock icon to enter clock settings.


UVO eServices with Premium Navigation System Clock Setup*:

Press the SETUP button, then press the on-screen Clock icon to enter clock settings.

QUICK TIP

Press the DONE button on the navigation screen to ensure changes are saved.


Aux/USB/iPod® Ports, & Power Outlets



(Located on Center Console)

AUX and USB ports can be used to connect a smartphone or MP3 player.

Rapid Charge USB Port* & AC Inverter*



(Located on Back of Center Console)

A Rapid USB charger* and power port is located in the Center Panel and rear of the Center Console

B AC Inverter*, 115V 150 watt, outlets are located in the rear of the Center console

QUICK TIP

The power outlets are inactive when the ENGINE START/STOP button is OFF.

REMINDER: Using the power outlet (accessory plug), USB charger and AC inverter for prolonged periods of time with the ENGINE START/STOP button in the ACC position (Engine OFF) could cause the battery to discharge.

For more information on the Aux/iPod® Ports, Power Outlets and AC Inverter, refer to the Owner's Manual.

Automatic Gear Shift with Sportmatic® Shifting

P: Park

D: Drive

R: Reverse

[+]: Sport Mode Upshift

N: Neutral


[-]: Sport Mode Downshift

Sport Mode: To enter Sport mode, move shift lever from D to left gate.

To shift while in Sport mode, move shift lever up [+] to upshift or down [-] to downshift.

QUICK TIPS

- Press brake pedal and depress release button to move gearshift from N to P, N to R or from P to any gear
- Sport mode downshifts are made automatically when the vehicle slows down. When the vehicle stops, 1st gear is automatically selected



QR CODE

Sportmatic® Shifting Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.




www.KuTechVideos.com/um13/2017

Paddle Shifters*

Paddle Shifters are operable when the shift lever is in the D position or in Sport mode.


Paddle Shifting: Pull the [+] or [-] paddle shifter once to shift up or down one gear.



REMINDERS:


- The paddle shifters can be operated when the vehicle speed is more than 6 mph
- When in Sport mode, pulling the left and right paddle shifters at the same time will NOT shift gears

Automatic Climate Control*



- A** Driver's temperature control knob
- B** AUTO (automatic control) button
- C** A/C on button
- D** Air Conditioning OFF button
- E** FRONT windshield defroster button
- F** REAR window defroster button
- G** Fan speed control button
- H** MODE Selection button
- I** CLIMATE information screen selection button
- J** A/C Rear Control ON/OFF button
- K** Air intake control button
- L** Passenger's temperature control knob
- M** SYNC temperature control selection button
- N** 3rd Row air conditioning ON/OFF button
- O** 3rd Row fan speed control knob

3rd Row Climate Control*




AWD (All-Wheel Drive) Lock*

When you select AWD Lock mode by pressing the AWD LOCK button, the AWD LOCK mode increases the drive power when driving on wet pavement, snow covered roads and/or off-road.

- This mode is used for climbing or descending sharp grades, off-road driving, driving on sandy and muddy roads, etc., to maximize traction.
- This mode automatically begins to deactivate at speeds above 19 mph (30 km/h) and is shifted to AWD AUTO mode at speed above 25 mph (40 km/h). If the vehicle decelerates to speeds below approximate 25 mph (40 km/h), however, the transfer mode is shifted into AWD LOCK mode again.

When the AWD LOCK mode is deactivated, a shock may be felt as the drive power is delivered entirely to the front wheels. This shock is not a mechanical failure.



(Located next to gear shift)

Automatic Climate Control*

Climate Control Auto Function

1. Press **AUTO** to select Full Auto Operation. The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected.
2. Set desired **Temperature**
3. Press **SYNC** to select Sync Temperature Control Operation


Defrost Outside Windshield:

1. Set Front **Fan Speed** to the highest position
2. Set **Temperature to Hot**
3. Press the **Front Defrost** button 

Defog Inside Windshield:

1. Set Front **Fan Speed** to desired position
2. Set desired **Temperature**
3. Press the **Front Defrost** button 

QUICK TIPS

- Defrost Mode  activates A/C and opens Fresh Air Vent to help dehumidify the air and improve Defroster performance
- During Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity
- Keep inside glass as clean as possible to reduce window fogging

Air Flow Modes

To select Air Flow Modes, press the mode buttons to cycle through to desired mode:




REMINDERS:

- When in AUTO mode, Air Flow Mode and Fan Speed do not display on the Climate Control Display
- Warm air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)
- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for DUAL Temperature Control

Your Automatic Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details

Manual Climate Control*



A FRONT fan speed control knob

B Front window defroster button

C REAR window defroster button

D Air conditioning button


E MAX A/C button

F Mode selection buttons


G Air intake control button

H Temperature control knob

Defrost Outside Windshield:

1. Set Fan Speed to the highest position
2. Set desired Temperature
3. Press the Defrost button 


Defog Inside Windshield:

1. Set Fan Speed to desired position
2. Set desired Temperature
3. Press the Defrost button 

REMINDER: Warm air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)

Your Manual Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details.

Rear Climate Control*



I 3rd Row air conditioning ON/OFF button


J 3rd Row fan speed control knob

Air Flow Modes

To select Air Flow Modes, press the Mode selection buttons:

 Face-Level

 Bi-Level

 Floor-Level

 Floor/Defrost-Level

Electronic Parking Brake (EPB)*

The Electronic Parking Brake (EPB) system utilizes an electric motor to engage the parking brake.

Applying the Parking Brake

Depress the brake pedal and pull up the EPB switch **A**. Ensure that the indicator light is illuminated on the instrument cluster.

Releasing the Parking Brake

The EPB will automatically release when the shifter is placed in Reverse or Drive.

To release EPB manually, depress the brake pedal, then press the EPB switch **A**, with the ignition switch in the ON position. Ensure that the indicator light is OFF.

REMINDERS:

- As a bulb check, the EPB malfunction indicator will illuminate for approximately 3 seconds when the ignition switch is turned ON
- If the warning light does not illuminate temporarily, or continues to remain lit, take your vehicle to an authorized Kia dealer and have the system checked
- The EPB should not be operated while the vehicle is moving
- A click or electric brake motor sound may be heard while operating or releasing the EPB, but these conditions are normal and indicate that the EPB is functioning properly

QUICK TIPS

- When leaving your keys with parking lot attendants or valet, make sure to inform them how to operate the EPB
- If parked on a steep incline/decline, pull up the EPB switch for more than 3 seconds for a firmer EPB application

Auto Hold*


The Auto Hold maintains the vehicle in a standstill even though the brake pedal is not depressed after the driver brings the vehicle to a complete stop by depressing the brake pedal.

Depress the brake pedal, start the engine and then press the AUTO HOLD button **B**. The white AUTO HOLD indicator will come on indicating the system is in standby.

Before the Auto Hold will engage, the driver's door, engine hood and trunk must be closed and the driver's seat belt must be fastened.


When coming to a complete stop by depressing the brake pedal, the AUTO HOLD indicator changes from white to green indicating the Auto Hold is engaged and EPB is applied. The vehicle will remain at a standstill even if you release the brake pedal.

If EPB is applied, Auto Hold will be released.



Heated Steering Wheel*

Seat Warmers / Ventilated Seats*



(Buttons located below Gear Shift)

Press Heated Steering Wheel button **A** to turn the Steering Wheel Heater on/off, while the ENGINE START/STOP button is in the ON position. Steering Wheel Heater will turn off automatically in 30 minutes, or when button **A** is pressed again to deactivate.

QUICK TIPS

- If ignition is turned OFF, then ON again within 30 minutes of Steering Wheel Heater being turned ON, the system will remain in the ON position
- System does NOT turn off when ignition is cycled. To turn off system, press the Heated Steering Wheel button **A**

B Seat Warmers

- Press button once for high setting (3 LEDs lit)
- Press button twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

C Ventilated Seats

- Press button once for high setting (3 LEDs lit)
- Press twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

QUICK TIP

With the seat warmer switch in the ON position, the heating system in the seat turns OFF or ON automatically depending on the seat temperature.

QR CODE

Heated and Ventilated Seats Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017


Front Seat Headrest Adjustment

Type A*

- To raise headrest, pull headrest up to the desired position
- To lower headrest, press the headrest down
- To adjust headrest forward, pull the headrest forward to the desired position
- To adjust headrest backward, pull headrest forward to the farthest position, and release

Type C*

- To raise headrest, pull headrest up to the desired position
- To lower headrest, press and hold the release button **A** and lower headrest to the desired position




REMINDER: The headrest will adjust fore and aft, but only locks in the aft direction (Type A).

Driver Position Memory System*

The integrated system stores into memory the position of the Driver's Seat and the Outside Rearview Mirrors.

To store positions into memory, first place the Gear Shift into P (Park) while the ENGINE START/STOP button is in the ON position. Then:



1. Adjust the Driver's Seat and the Outside Mirrors
2. Press the SET button **B** on the control panel. System will beep once
3. Press one of the memory buttons **C** within 5 seconds. The system will beep twice when memory has been stored



(Buttons located on Driver's Door Panel)

Power Adjustable Driver's Seat*

Move/Press controls to adjust Seat, Seat Cushion, Seatback, Lumbar and Seat Cushion Extension



Seat

Seat Cushion

Seatback

Lumbar

Seat Cushion Extension


Manual Adjustable Driver's Seat*

Pull lever **E** to slide Seat forward/backward.

Pull/press lever **F** to adjust Seat height.

Pull lever **G** to adjust Seatback recline.

Press **H** to adjust Lumbar support.



QUICK TIP

When adjusting seat forward or backwards, ensure seat clicks or locks into place before driving the vehicle.


2nd-Row Folding Seat

Folding 2nd-Row Seat

1. Lower the 2nd-Row Seat Headrest to the lowest position
2. Pull up on the Seatback folding lever **A** or strap and fold the Seatback down

Unfolding 2nd-Row Seat

1. Lift the folding Seatback lever **A** and move the Seatback backward **B**
2. Then lift the lever again **A** or return it to an upright usable position **B**




QUICK TIPS

- When you return Seatback to its original position, ensure it locks (clicks) into place
- It may be necessary to slide the front Seat forward and adjust the front Seatbacks to fully lower rear seats
- Lower Rear Headrests to the lowest position

2nd-Row Walk-In Seat*

To enter the 3rd-Row Seat* area, do the following steps:

1. Place the Seatbelt into the guide clip and tighten the Seatbelt by pulling up
2. Pull lever **C** located on the 2nd-Row Seatback
3. Fold the Seatback forward and slide to the farthest forward position
4. Return Seatback to its original position and ensure it locks (clicks) into place



(Lever located on 2nd-Row Seatback)

For more information on 2nd-Row Walk-In Seat operation, refer to the Owner's Manual.

QR CODE

2nd & 3rd Row Folding Seats Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.




www.KuTechVideos.com/um13/2017

3rd-Row Folding Seat*

Folding 3rd-Row Seat


1. Fully lower headrest **A**
2. Pull Seat folding strap **B** located on the Seatback
3. Fold Seat down



For more information on 3rd-Row Seat operation, refer to the Owner's Manual.

2nd-Row Auto Folding Seat*

Pull lever **D** to release and automatically fold 2nd-Row Seatback down.



(Located on rear quarter-trim panels)

QR CODE

2nd & 3rd Row Folding Seats Video

To view a video on your mobile device, snap this QR Code or visit the listed website.


Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

Sunvisor

Use the Sunvisor to shield direct light through the front or side windows. Slide the Sunvisor out and adjust as needed.



REMINDERS:


- Sunvisor may not shield all direct light
- The Sunvisor may impair visibility if not adjusted properly
- Do not operate the vehicle if Sunvisor is impairing your visibility
- Be aware of seating position when adjusting or swinging Sunvisor around to and from the front or side windows

Sunglasses Holder

To open the sunglasses holder **F**, lightly press the cover and the holder will slowly open **G**.

Place your sunglasses with the lenses facing out.


To close the sunglasses holder push it up.



Remote Keyless Entry (Folding Key)*

- A** Press the release button to unfold the key
- B** Press to lock All Doors
- C** Press to unlock Driver's Door: Press twice in 4 seconds to unlock All Doors and Rear Hatch
- D** Manual Rear Hatch: Press and Hold for more than 1 second to unlock rear and manually open.
- D** Power Liftgate*: Press and hold for more than 1 second to open
- E** Press and hold more than a half second for Panic Alarm. To turn OFF Alarm, press any button

Remote button configuration may vary depending on vehicle options.



Double-Turn Lock/Unlock All


- Turn clockwise once to unlock Driver's Door
- Turn clockwise again within 4 seconds to unlock All Doors
- Turn counterclockwise once to lock All Doors

Smart Key*

- A** Press to lock All Doors
- B** Press to unlock Driver's Door. Press twice within 4 seconds to unlock All Doors.
- C** Manual Rear Hatch: Press and hold to unlock Rear Hatch and manually open

REMINDERS:

- The Rear Hatch does not automatically open when the **C** button is pressed.
- The Rear Hatch unlocks when the Smart Key fob is within close proximity of the vehicle.
- C** Power Liftgate*: Press and hold for Power Liftgate to open automatically. Press again at any time to stop. Press again to automatically close
- D** Press and hold for more than a half second for Panic Alarm. To turn off Alarm, press any button
- E** Press to release mechanical key
- F** Mechanical key



QR CODE

Engine Start/Stop Button & Smart Key Video

To view a video on your mobile device, snap this QR Code or visit the listed website.


Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

Driver's Door Lock/Unlock button **G**:


- Press button once to unlock driver's door
- Press again within 4 seconds to unlock all doors
- Press again to lock all doors



Remote button configuration may vary depending on vehicle options.

Mechanical Key **H**:

- Press button on back of key fob to release Mechanical Key
- Use to lock/unlock driver's door




QUICK TIPS

- The Smart Key's signal can be blocked by the normal operation of a cellular phone or smartphone. To help prevent this, store each device separately
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the ENGINE START/STOP button (Lock button side closest) and press to start engine

Power Liftgate (Tailgate)*

Inside the Vehicle:

Press and hold the Power Liftgate Open/Close button **A** to automatically open/close the Liftgate.



(Button located on Driver's Panel)

Smart Key:

To open the Power Liftgate, press and hold the Liftgate button **D** until the Liftgate begins opening. Press again to close.


REMINDER: Pulling the Rear Hatch upward by the handle or pressing the button a second time will interrupt the automatic opening of the Power Liftgate.



Outside the Vehicle:

To open Power Liftgate automatically, press the Rear Hatch Release button **B**.

Close by pushing Power Liftgate Close button **C**.



(Located on Liftgate lip near latch)

Power Liftgate (Tailgate) Opening Height User Setting

The height setting of a fully opened liftgate (tailgate) can be adjusted by the following steps:

1. Position the liftgate (tailgate) manually to the preferred height
2. Press and hold the Power Liftgate Close button **C** for more than 3 seconds
3. A system beep will sound twice indicating the height setting has been saved


The liftgate (tailgate) will then open to the set height. To change setting again, repeat steps 1-3.

Power Liftgate (Tailgate)*

Smart Liftgate*

When the Smart Key fob is on your person and you are near the back of the vehicle, within close proximity, the hazard lights will blink and a chime will sound for about 3 seconds as an alert that the Power Liftgate is about to open. Then the alert system will blink and chime two additional times before opening the Power Liftgate.

The Smart Liftgate feature is off by default. To enable the Smart Liftgate, go to User Settings in the LCD Instrument Cluster modes.



QUICK TIP

During the Smart Liftgate alert, the Smart Liftgate can be deactivated with the Smart Key by pressing any button on the key fob.

REMINDERS:

- All doors are closed and locked after about 15 seconds
- If the POWER DOOR OFF button is depressed, the Smart Liftgate will not operate.
- The Smart Liftgate feature will not operate when:
 - The doors are recently closed and locked, and the Smart Key is still detected after 15 seconds near the vehicle or within 60 inches of the door handles
 - A door is not locked or closed
 - The Smart Key is in the vehicle

For more information on the Smart Liftgate operation, please refer to the Owner's Manual.

QR CODE

Smart Tailgate Video

To view a video on your mobile device, snap this QR Code or visit the listed website.


Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

HomeLink® with Auto-Dimming Rearview Mirror*

- | | |
|---------------------------|---------------------------------|
| A HomeLink® button | E Glare detection sensor |
| B HomeLink® button | F Automatic dimming ON |
| C Indicator light | G Automatic dimming OFF |
| D HomeLink® button | |



The HomeLink® / Auto-Dimming Rearview Mirror* is designed to reduce glare from a vehicle's headlights located in the rear and also connect up to three electronic transmitters into one location.

- To turn automatic dimming ON, press **I** button **F**
- To turn automatic dimming OFF, press **O** button **G**

REMINDER: Mirror indicator light **C** will illuminate when automatic dimming is ON.

QUICK TIPS

- You can reprogram a single HomeLink® button by repeating Step 2
- Erasing programmed buttons will delete all trained transmitters

How to Sync Transmitter with HomeLink®*

If programming for the first time, begin with Step 1 (repeating this step will delete all information).

To program non-rolling and rolling code garage door openers and other devices:

1. Press and hold the left **A** and center **D** buttons simultaneously until the indicator light **C** begins to flash (to reprogram buttons, skip this step)
2. Press and hold the desired button **A B D** and hold the button on the transmitter while it is approximately 1 to 3 inches away from the mirror. The HomeLink® Indicator light **C** will flash rapidly once the frequency signal has been successfully programmed

To finish programming rolling code garage door openers, complete these steps:

3. Locate the “learn” or “smart” button on the garage door's motor head unit. Press and release the button and complete Step 4 within 30 seconds
4. Firmly press and release the programmed HomeLink® button up to three times

Operating HomeLink®:

Press one of the programmed HomeLink® buttons.

Erasing programmed buttons:

Press and hold the left **A** and center **D** buttons simultaneously for approximately 20 seconds, and then release both buttons within 30 seconds.

If your garage door opener was manufactured in 2011 or later, and you're unable to program your vehicle's HomeLink® system, you may need to purchase a HomeLink Repeater Kit. For more information, go to www.HomeLink.com or call (800) 355-3515.

Map/Room Lamps

Automatic turn off function*

The interior lights automatically turn off approximately 30 seconds after the ENGINE START/STOP button is OFF.


Map/Room Lamp Operation

Press the button **A** to turn the Map Lamp ON/OFF. Press button **B** to turn the Driver's/Passenger's Map Lamps ON/OFF. This light produces a spot beam for convenient use as a map lamp or as a personal lamp for the driver or the front passenger.

The Map Lamp turns ON when any door is opened or the ignition is turned OFF. When all doors are locked or the ignition is ON, the Map Lamp will turn OFF immediately.

Map/Room Lamp button **C** – When pressed and a door is opened, or doors are unlocked from the Smart Key, the Map and Room Lamps turn ON for approximately 30 seconds.

Room Lamp – Press the lens **D** to turn the Room Lamp ON/OFF.



(Front overhead console)

Panoramic Sunroof Operation

The Sunroof and Sunshade operation is controlled through multidirectional lever **E**. The ignition needs to be ON to operate the sunroof/sunshade.

To slide the Sunshade and Sunroof:

- Auto Open: Slide the lever **E** backward to the farthest position and release
- Auto Close (Sunroof only): Slide the lever **E** forward to the farthest position and release

Tilt the Sunroof:

- Raise: Push lever **E** upward
- Lower: Pull lever **E** downward
- Auto Close Sunroof and Sunshade: Slide the Sunroof lever **E** forward to the farthest position

REMINDERS: Sunshade needs to remain OPEN while Sunroof is open and vehicle is moving

QUICK TIPS

- When doors are unlocked by the Smart Key*, the lamp turns ON for approximately 30 seconds
- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 3 seconds after the system is in armed stage
- Using interior lights for an extended period of time may cause battery discharge

QUICK TIP

To stop the Sunroof/Sunshade at any position, push or pull the Sunroof control lever in any direction.

Back-Up Warning System (Rear Parking Assist System)*

The Back-Up Warning System is not a safety device. The Back-Up Warning System is a supplemental system that assists the driver by chiming if any object is detected within the sensing area to the rear and side of the vehicle when backing up. When the ignition is ON, the system is activated.


The Backup Warning System is activated when ignition is on, and the button **A** is not depressed (LED not lit).

To deactivate the Backup Warning System, press the button **A** (LED lit).

REMINDERS:

- If the vehicle is moving at speeds over 3 mph, the system may not activate correctly
- When more than two objects are sensed at the same time, the closest one will be recognized first

The Back-Up Warning System is not a substitute for proper and safe backing-up procedures. Always drive safely and use caution when backing up. The Back-Up Warning System may not detect every object behind the vehicle





Rear-Camera Display

The Rear-Camera Display system is not a safety device. It is a supplemental system that displays the view behind the vehicle through the Standard Audio System (Type B), UVO eServices with Premium Navigation* or UVO eServices System* while the vehicle is in Reverse.

The Rear-Camera Display activates when the:

- Ignition or the ENGINE START/STOP button* (Green Light) is in the ON position
- Gear Shift Lever is in the R (Reverse) position



REMEMBER: While camera is active, only the volume controls on the Audio System can be operated.


The Rear-Camera Display is not a substitute for proper and safe backing-up procedures. The Rear-Camera Display may not display every object behind the vehicle. Always drive safely and use caution when backing up.

Hood Release Lever and Latch


Opening the Hood:

1. Pull the Hood Release Lever **A** to unlatch the Hood
2. In the front of the vehicle, lift the Hood slightly, push the secondary Latch **B** to the left inside of the Hood's center and lift the Hood
3. It will open by itself after it has been raised about half way.

REMINDER: Open the Hood only after turning the engine off, on a flat surface, with the gear shift in P (Park) position and setting the parking brake.



(Lever located near floor below Driver's Panel)




(Latch located inside hood)

Closing the Hood:

Lower the Hood about halfway and then press down to securely lock in place.


Fuel Cap/Malfunction Indicator (Check Engine Light)

Tighten for ONE CLICK to prevent Malfunction Indicator  from illuminating.




REMINDER: The Fuel Filler Door Release button is located on the driver's button panel, left of the Steering Wheel.

Child Safety Locks

Located on the rear edge of the rear passenger doors, turn the Child Safety Lock to the lock position  to disable the inner door handles from opening the rear doors.

REMINDER: Child Safety Lock is located on rear passenger's door jamb.



(Lock located on rear passenger inside door jamb)

QR CODE

One-Click Fuel Cap Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to page 2 for more information.



www.KuTechVideos.com/um13/2017

Occupant Detection System (ODS) / Passenger Airbag Off Indicator



ODS detects the presence and position of the front passenger and adjusts or turns off airbag deployment accordingly.

Depending on the situation and type of accident, the system may:


- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the "PASSENGER AIR BAG OFF" light will illuminate.

Seat Belts

To properly fasten your seat belts:

1. Insert the belt tongue plate **A** into the buckle **B** until it clicks
2. Position the lap portion of the belt across your lap as **LOW ON THE HIPS** as possible **C**. Adjust the belt to a **SNUG FIT** by pulling up on the shoulder portion **D**



REMINDER: For maximum protection, always wear your seat belt.


QUICK TIP

The seat belt warning chime operates for driver's seat only.

Seat Belt Retractor Locks

Retractor locks allow lap/shoulder safety belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a **STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS**, seatbelt retractors will automatically lock the belts to reduce the risk of injury.



For more detailed information regarding your vehicle's safety belts, please refer to your Owner's Manual and the separate brochure titled "Understanding Your Safety Belt & Supplemental Restraint System."

Normal Maintenance Schedule

When your vehicle requires service, remember that your dealer knows your vehicle best. Your dealer has factory-trained technicians, recommended special tools, genuine Kia replacement parts and is dedicated to your complete satisfaction. For expert advice and quality service, see your authorized Kia dealer.

7,500 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Engine oil and filter (Every 7,500 miles; 2.0L Turbo-GDI – At first, replace at 3,000 miles, then every 6,500 miles)

INSPECT*

- Battery condition
- Air cleaner filter
- Vacuum hose

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

15,000 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Climate control air filter (For evaporator and blower unit)
- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)

INSPECT*

- | | |
|--------------------------------|---|
| • Battery condition | • Front brake disc/pads, calipers |
| • Air cleaner filter | • Propeller shaft (AWD) |
| • Vacuum hose | • Rear brake disc/pads |
| • Air conditioning refrigerant | • Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint |
| • Brake hoses and lines | • Suspension mounting bolts |
| • Drive shafts and boots | |
| • Exhaust pipe and muffler | |

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your UVO eServices account by logging into your UVO App or your account on MyUVO.com (Vehicles equipped with UVO eServices only - See page 22/23 for setup information)

Normal Maintenance Schedule (continued)

22,500 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)
- Climate control air filter (For evaporator and blower unit)

INSPECT*

- Battery condition
- Air cleaner filter
- Vacuum hose

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

30,000 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Climate control air filter (For evaporator and blower unit)
- Air cleaner filter
- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)

INSPECT*

- | | |
|-----------------------------------|---|
| • Battery condition | • Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint |
| • Air cleaner filter | • Suspension mounting bolts |
| • Vacuum hose | • Brake fluid |
| • Air conditioning refrigerant | • Fuel filter ^{**2} |
| • Brake hoses and lines | • Fuel lines, fuel hoses and connections |
| • Drive shafts and boots | • Fuel tank air filter ^{**2} |
| • Exhaust pipe and muffler | • Parking brake |
| • Front brake disc/pads, calipers | • Vapor hose and fuel filler cap, fuel tank |
| • Propeller shaft (AWD) | |
| • Rear brake disc/pads | |

*And, if necessary, adjust, correct, clean or replace. ** If equipped.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives. ² Fuel filter & fuel tank air filter are considered to be maintenance free but periodic inspection is recommended for this maintenance schedule depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem etc., replace the fuel filter immediately regardless of maintenance schedule and consult an authorized Kia dealer for details.

Normal Maintenance Schedule (continued)

37,500 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)

INSPECT*

- Battery condition
- Air cleaner filter
- Vacuum hose
- Rear axle oil (AWD)*²
- Transfer case oil (AWD)*²

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives. ² Transfer case oil and rear axle oil should be changed anytime they have been submerged in water.

45,000 miles

PERFORM

- Rotate tires
- Fuel additive¹ (Every 7,500 miles)

REPLACE

- Climate control air filter (for evaporator and blower unit)
- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)
- Spark plugs (iridium coated) - 2.0T-GDI

INSPECT*

- | | |
|--------------------------------|---|
| • Battery condition | • Front brake disc/pads, calipers |
| • Air cleaner filter | • Propeller shaft (AWD) |
| • Vacuum hose | • Rear brake disc/pads |
| • Air conditioning refrigerant | • Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint |
| • Brake hoses and lines | • Suspension mounting bolts |
| • Drive shafts and boots | |
| • Exhaust pipe and muffler | |

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

Normal Maintenance Schedule (continued)

52,500 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)

INSPECT*

- Battery condition
- Air cleaner filter
- Vacuum hose

60,000 miles

PERFORM

- Rotate tires
- Add fuel additive¹ (Every 7,500 miles)

REPLACE

- Climate control air filter (For evaporator and blower unit)
- Air cleaner filter
- Engine oil and filter (Every 7,500 miles)
(2.0L Turbo-GDI – replace every 6,500 miles)
- Coolant (First, 60,000 miles, thereafter every 30,000 miles)

INSPECT*

- | | |
|---|---|
| <ul style="list-style-type: none"> • Battery condition • Air cleaner filter • Vacuum hose • Air conditioning refrigerant • Brake hoses and lines • Drive shafts and boots • Exhaust pipe and muffler • Front brake disc/pads, calipers • Propeller shaft (AWD) • Rear brake disc/pads | <ul style="list-style-type: none"> • Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint • Suspension mounting bolts • Brake fluid • Fuel filter*² • Fuel lines, fuel hoses and connections • Fuel tank air filter (if equipped)*² • Parking brake • Vapor hose and fuel filler cap, fuel tank • Valve clearance³ • Drive belts (First 60,000 miles, thereafter every 15,000 miles)*⁴ |
|---|---|

*And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

And, if necessary, adjust, correct, clean or replace.

¹ If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives. ² Fuel filter & fuel tank air filter are considered to be maintenance free but periodic inspection is recommended for this maintenance schedule depends on fuel quality. If there are some important safety matters like fuel flow restriction, surging, loss of power, hard starting problem etc., replace the fuel filter immediately regardless of maintenance schedule and consult an authorized Kia dealer for details. ³ Inspect for excessive tappet noise and/or engine vibration and adjust if necessary. ⁴ The drive belt should be replaced when cracks occur or tension is reduced excessively.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and use of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

Airbags: For maximum protection, always wear your seat belt.

Android Auto: Android Auto is a trademark of Google, Inc. Android™ is a registered trademark of Google, Inc. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

Apps: All information contained herein was based upon the latest available information at the time of appstore registration. Descriptions are believed to be correct, and Kia Motors Corporation (KMC) makes every effort to ensure accuracy, however, accuracy cannot be guaranteed. From time to time, KMC may need to update or make changes to the vehicle features and other vehicle information reported in this app. KMC, by the publication and dissemination of this material, does not create any warranties, either express or implied, to any Kia products. Contact your local Kia dealer for the most current information.

Autonomous Emergency Braking System (AEB): Autonomous Emergency Braking is not a substitute for safe driving, and may not detect all objects in front of vehicle. Always drive safely and use caution.

Bluetooth® Wireless Technology: The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc., and any use of such marks by Kia is pursuant to license. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.

Driver Assist Features - Advanced Smart Cruise Control (ASCC), Back-Up Warning System (Rear Parking Assist System), Blind Spot Detection (BSD) with Lane Change Assist, Rear Cross Traffic Alert (RCTA), Lane Departure Warning System, Reverse Parking Aid System, Rear-Camera Display, Surround View Monitor (SVM): These features are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution.

Electronic Stability Control (ESC)/ Traction Control System (TCS)/Hill-start Assist Control (HAC): No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive responsibly.

Engine Start/Stop Button with Smart Key: Always come to a complete stop before turning the engine on or off. However, if you have an emergency while the vehicle is in motion and must turn the engine off, you can turn the engine off to the ACC position by pressing the Start/Stop button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the engine by pressing the Start/Stop button with the shift lever in Neutral (N). With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.

Forward Collision Warning System (FCWS): Forward Collision Warning System is not a substitute for safe driving and may not detect all objects in front of the vehicle. Always drive safely and use caution.

Front Seat Headrest Adjustment: Never attempt to adjust headrests when vehicle is in motion.

Google Play™ Store is a trademark of Google, Inc. © 2012 Google Inc. All rights reserved. Google and the Google Logo are registered trademarks of Google Inc.

HomeLink®: Homelink® is a registered trademark of Genent Corporation

iPod® is a registered trademark of Apple Inc. iPod® mobile digital device sold separately, and connectivity requires the Kia accessory cable.

Navigation: Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

Occupant Detection System (ODS): Kia vehicles use a number of different ODS types that vary by model.

Pandora® internet radio: Pandora® is a registered trademark of Pandora Media, Inc.

Parking Assist System: The Parking Assist System is not a substitute for proper and safe backing-up procedures. The Parking Assist System may not detect every object behind the vehicle. Always drive safely and use caution when backing up.

Roadside Assist: 24-hour Enhanced Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.

Seat adjustments: Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.

Seat belts: For maximum protection, always wear your seatbelt.

Seat warmers: Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.

SiriusXM®: SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. **If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com.** Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area in AK and HI. © 2015 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.

Smart Liftgate/Smart Power Liftgate: Driving with the trunk open may be unlawful and can draw dangerous exhaust fumes into your vehicle; if you choose to do so, keep air vents and all windows open for proper ventilation.

Sportmatic® is a registered trademark of Kia Motors America.

Steering-wheel-mounted controls: Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.

Sunvisors: Sunvisor may not shield all direct light. Do not operate the vehicle if sunvisor is impairing your visibility.

Tilt/Telescoping Steering Wheel: Never attempt to adjust steering wheel position when vehicle is in motion.

Tire Pressure Monitoring System (TPMS): Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.

UVO eServices: Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.

UVO eServices app: App uses your smartphone data service. Normal cellular service rates will apply.

UVO eServices with Navigation/Premium Navigation: Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.

Vehicle Diagnostics: Vehicle Diagnostics checks powertrain, chassis and air bag systems, and is not a substitute for maintenance. See UVO eServices Maintenance Feature or Owner's Manual for maintenance schedule




SORENTO CUSTOMER DELIVERY CHECKLIST

KEY FEATURE WALKTHROUGH


- Standard Audio System (Type A)*
— page 20

For further operational information, refer to the Owner's Manual.



- Standard Audio System (Type B)*
— page 21

For further operational information, refer to the Owner's Manual.




- UVO eServices System* — page 22

For further operational information, refer to the UVO System User's Manual.




- UVO eServices with Premium Navigation* — page 23

For further operational information, refer to the Car Multimedia System User's Manual.




- ASCC / Cruise Control — page 18-19

Demonstrate operation



- Bluetooth® Wireless Technology

— pages 16-17
Demonstrate operation



- Aux/USB/Pod® Ports, Power Outlets & AC Inverter* — page 25
- Blind Spot Detection (BSD)* — page 10
- Clock Setup — page 25
- Engine Start/Stop Button — page 13
- HomeLink® with Auto-Dimming Rearview Mirror — page 38
- Lane Departure Warning System (LDWS)* — page 11
- Passenger Airbag Off Indicator — page 44
- Panoramic Sunroof Operation* — page 41
- Rear-Camera Display* — page 42
- Seat Warmers / Ventilated Seats* — page 31
- Smart Key — page 37
- Sunvisor — page 36
- Tire Pressure Monitoring System (TPMS) — page 5

*If equipped

DURING DELIVERY

- Explain first service process and schedule first service appointment
- Tour Parts & Service departments, introduce staff and explain value of Kia Parts and Service
- Review recommended maintenance schedule and maintenance requirements to validate warranty
- Review business hours and Customer 360° Care
- Review the Kia 10-Year/100,000-mile warranty program
- Ensure 100% satisfaction with sales and no problems with the vehicle
- Confirm time and best contact number for initial dealer follow-up

Sales Consultant: _____ Date: _____

Sales Manager: _____ Date: _____

Customer: _____ Date: _____



SORENTO CUSTOMER DELIVERY CHECKLIST

Owner's Name: _____ VIN: _____ Mileage: _____


Dealership Name: _____ Sales Consultant: _____ Date: _____

BEFORE DELIVERY


- Test and confirm "Good Battery" using the Kia GR8-1299 battery tester and affix Results Label
- Verify all tire pressures are to spec (see driver's door label) LF _____ LR _____ RF _____ RR _____
- Verify proper operation of Remote Keyless Entry and Smart Key lock/unlock
- Ensure floor mats are snapped into place (if applicable)
- Verify vehicle is clean (interior and exterior), in good condition and free of chips and scratches
- Ensure all key documents are in the vehicle (Owner's Manual, Warranty and Consumer Information booklet, Tire Warranty booklet and Features & Functions Guide and any audio system user's manual.)

KEY FEATURE WALKTHROUGH

- Air Conditioning / Climate Control - page 27-29
Demonstrate Air Flow Modes, Defog and Defrosting Windshield Fan Speed




Automatic*



Manual*


- Front Seat Headrest Adjustment – page 32



(Type C)


- Windshield/Rear Wipers & Washers – page 15

- Move lever Up/Down to change Wiper modes
- Push switch to adjust Intermittent Wipe
- Pull lever to spray and wipe



MIST: Single wipe
 OFF: Wiper off
 INT: Intermittent wipe
 LO: Slow wipe
 HI: Fast wipe

- Rotate Rear Wiper switch to change Wiper modes
- Push to spray and wipe



HI: Fast wipe
 LO: Slow wipe
 OFF: Wiper off

(front operation)

(rear operation)



© 2016 Kia Motors America, Inc. All rights reserved.

Part Number: UX170-PS-004

Consumer - Roadside Assistance: 1-800-333-4KIA (4542)