

U.S. ROADSIDE ASSISTANCE

FOR COMPLIMENTARY HELP, CALL 1-800-241-3673

Quick access to the information below will get help to you faster. Know your vehicle's mileage and specific location.

NAME _____

VIN _____

Roadside Assistance services are available from the warranty start date and last for 5 years or 60,000 miles, whichever comes first.

CANADA ROADSIDE ASSISTANCE

NAME _____

VIN _____

See Warranty Guide for complete details.

Download the Sykes4Ford Roadside Assistance App for access to your roadside assistance services.

Ford Motor Company reserves the right to modify or discontinue Roadside Assistance at any time. Certain restrictions apply to Roadside Assistance benefits.

For further details, call
1-800-241-3673 (United States) **1-800-665-2006** (Canada)

ROADSIDE ASSISTANCE

FLAT TIRES

It does seem that today nobody gets a flat tire, but what if you did? Roadside Assistance will change your tire for you. Tire change service requires the customer to have a usable spare tire.

DEAD BATTERIES

Sure, even a good battery can go dead for one reason or another. Roadside Assistance will give your vehicle the jump-start it needs.

LOCK OUTS

It's embarrassing, but it happens. We'll get you back in, fast... and it's free. Key replacement cost is the customer's responsibility.

TOWING

Your car's not working... and you don't know why. Just make the call and we'll be there. Warranty Towing, Non-warranty Towing and Collision Towing are available.

FUEL DELIVERY

You ran out of gas with no fuel station in sight. We'll bring the gas to you FREE. Limited to two, no-charge occurrences within a 12-month period. For the amount provided, please see your Owner's Manual.

TRAILERS

If your vehicle requires towing while hauling a trailer, Roadside Assistance provides coverage for towing up to a maximum per event. Please see your Owner's Manual for details.

WINCH OUT

If you should get stuck, we'll pull you out (limited to events occurring within 100 feet (30 m) of a paved/county-maintained surface). Does not include winch out from standing water (recoveries).

Warranty Information:

Your vehicle comes with a New Vehicle Limited Warranty. The express warranties of the New Vehicle Limited Warranty are in substitution for and exclude all other liabilities of any kind whether arising under statute, in tort, by implication of law or otherwise including, to the full extent as may be allowed by law, liability for any other representations respecting the vehicle, statutory warranties or implied warranties or conditions as to its merchantability or fitness.

Download a FREE electronic copy or order one FREE printed copy of the most up-to-date Warranty Guide by visiting the Owner Manuals section of owner.ford.com. (United States)

For Canada, visit ford.ca/warranty.

For Limo/Livery/Hearse vehicles: View and download your Warranty Guide by visiting the Warranty Information section of the Fleet website, fleet.ford.com/limo. (United States only)



This Quick Reference Guide is not intended to replace your vehicle Owner's Manual, which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

United States

Ford Customer Relationship Center

1-800-392-3673 (FORD)

(TDD for the hearing impaired: 1-800-232-5952)

owner.ford.com



Canada

Ford Customer Relationship Centre

1-800-565-3673 (FORD)

(TDD for the hearing impaired: 1-888-658-6805)

ford.ca



AUGUST 2020

FIRST PRINTING

LITHO IN U.S.A.



BRONCO
SPORT


QUICK REFERENCE GUIDE



Cargo and load capacity limited by weight and distribution.
Vehicle shown with aftermarket accessories.

20
21

COMMONLY USED VOICE COMMANDS

Press the voice button  on the steering wheel and then say:

General

- Cancel
- Help
- Main Menu ¹
- List of Commands

Audio

- Radio ¹
- AM <frequency number>
- FM <frequency number>
- *Bluetooth* Stereo
- USB

Navigation ^{1,2}

- Find an Address
- Find a Place
- Drive Home
- Drive to Work
- Show Previous Destinations
- Cancel Route
- Show Route
- Repeat Instruction
- Show Map

Phone

- Pair Phone
- Call <contact name>
- Call <contact name> <location> ¹
- Dial <number>

SiriusXM[®] Traffic and Travel Link ^{1,2,3}

- Show Traffic
- Show Weather Map
- Show Fuel Prices
- Show 5-Day Forecast

Apps

- Mobile Applications
- List Applications
- Find Applications
- <App Name> Help ¹

¹ SYNC 3 only

² if equipped

³ SiriusXM may not be available in all markets. Activation and a subscription are required.

Some services may not be available in your area. Refer to the *SYNC 3* chapter in your *Owner's Manual*, visit the website or call the toll-free number for more information.

For U.S. customers: Visit owner.ford.com or call 1-800-392-3673.

For Canadian customers: Visit syncmyride.ca or syncmaroute.ca or call 1-800-565-3673.

CONTENTS

14

Four-Wheel Drive



Instrument Panel 4-7
SYNC 3 8-10
Off Road 11-17
Outdoor Enablers 18-19
Convenience 20-23
Function 24-26
Essential Features 27

15

Towing Points



18

Power Points



Learn More About Your New Vehicle

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.



owner.ford.com (U.S.)



ford.ca (Canada)

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



INSTRUMENT PANEL

1 LIGHTING CONTROL

Use the dial to make a selection. An indicator illuminates next to the active selection.

- Lamps off
- Parking lamps, instrument panel lamps, license plate lamps and rear lamps
- Autolamps
- Headlamps on

2 FRONT FOG LAMPS*

You can switch on the front fog lamps by pressing the button on the lighting control.

Note: Only use fog lamps during reduced visibility, for example heavy fog, snow or heavy rain.

3 ADAPTIVE CRUISE CONTROL*

Adaptive Cruise Control adjusts your speed to maintain a set distance between your vehicle and the vehicle in front of you in the same lane. You can select from one of four gap settings by pressing the gap controls on the steering wheel. To set a cruise speed, switch cruise control on by pressing the button. Once you switch the system on, the control icons display. Accelerate to your desired speed and press the **SET+** or **SET-** button. An indicator light, the current gap setting and your set speed appear in the information display. Press to cancel cruise control, press the **RES** button to return to the set speed and gap setting and press the cruise control button or switch off the ignition to turn cruise control off. The system can also bring your vehicle to a complete stop and may resume going forward in stop-and-go traffic. Adaptive Cruise Control with Lane Centering* is designed to help keep your vehicle in the center of the lane by applying continuous assistance steering torque input toward the lane center on highways. To switch it on, press the button. The system will only activate when you have both hands on the wheel and the system detects both lane markings. Intelligent adaptive cruise control sets the vehicle speed to the speed limit detected by the speed sign recognition system.

Note: Driving aids do not replace the need to watch where the vehicle is moving and brake when necessary. Refer to the *Adaptive Cruise Control* chapter in your *Owner's Manual* for safety information, more details and limitations.

4 SERVICE ENGINE SOON LIGHT

Lights briefly when you switch on the ignition. If it remains on or is flashing after you start the engine, the On-Board Diagnostics system has detected a problem. Drive in a moderate fashion and contact an authorized dealer as soon as possible.

5 AUTOWIPERS*

The autowiper system turns the wipers on only when moisture is present on the windshield. You can switch them on using the wiper stalk. Use the rotary control to adjust the sensitivity of the autowipers. A low sensitivity means the wipers turn on when the system detects a large amount of moisture on the windshield. A high sensitivity means the wipers turn on when the rain sensor detects a small amount of moisture on the windshield. Autowipers default to on and remain on until you switch them off in the information display.

*if equipped





INSTRUMENT PANEL

6 STEERING WHEEL CONTROLS

- Press to increase or to decrease volume levels.
- Press to decrease volume levels.
- Press to access the previous or next media selection.
- Press to silence the current media.
- Press to access voice recognition.
- Press to go back or to exit.
- Press to access phone mode or to answer a phone call.
- Press to end a phone call.
- Press to enter the submenu.

Use the control and the OK button to select and confirm options for SYNC 3*.

7 KEYLESS STARTING*

You can start your vehicle by pressing the **START STOP** button while fully pressing down on the brake pedal. Press the button again, without applying the brake, to switch the engine off. If you leave your vehicle idling for an extended period of time, the engine shuts down automatically. Before this happens, a message appears in the information display, allowing you time to override the shutdown feature. If you try to leave the vehicle when it is still on, the horn will sound twice.

Note: A valid key must be inside the vehicle for the ignition to start.

8 HEATED SEATS*

For heated front seats, press repeatedly to cycle through the various heat modes and off.

9 HAZARD WARNING FLASHER

10 AUTO-START-STOP*


The system automatically turns off the engine when you stop your vehicle to help reduce fuel consumption. Your vehicle may restart to maintain interior comfort or recharge the battery. The engine restarts automatically when you release the brake pedal.

The system turns on automatically each time you start your vehicle. Press the button on the center console to deactivate the feature. Deactivating the feature lasts only 1 key cycle. Press the button again to restore Auto-Start-Stop function.

11 DRIVE MODE CONTROL

Goes Over Any-type of Terrain (G.O.A.T.) modes control delivers a driving experience through a suite of sophisticated electronic vehicle systems. The system automatically tailors your vehicle configuration for each mode you select on the console mounted controller. Please see page 17 for more information.





SYNC 3 allows you to interact with a variety of features using the touchscreen and voice commands. The system provides easy use of the system elements, like audio, phone, mobile apps and settings.

*if equipped


USING THE TOUCHSCREEN


Use the touchscreen to navigate the SYNC 3 features. The status bar on the top of the screen contains the home button, clock, outside temperature and status bar icons that inform you about the system. The feature bar allows you to select system features, like audio and settings. For your safety, some features are speed-dependent. Their use is limited to when your vehicle speed is less than 3 mph (5 km/h).

UPDATING YOUR SYSTEM

System updates are available through the local Ford website by USB or by connecting your vehicle to a Wi-Fi network connection. With a network connection, you can have your SYNC 3 system update automatically as well. Please see the **SYNC 3** chapter in your *Owner's Manual*.

USING VOICE RECOGNITION


Using voice commands allows you to keep your hands on the wheel and focus on what is in front of you. To activate the SYNC 3 voice commands, press the voice button  on the steering wheel and wait for the prompt.

- Press the  button during any system voice prompt to interrupt the prompt and begin your voice command.
- To adjust the volume of the system voice prompts, turn the volume control when a voice prompt is playing.
- To use Siri on your iOS device, press and hold the voice control button on the steering wheel.

You can find the available voice commands in the **SYNC 3** chapter of your *Owner's Manual* or in the **Commonly Used Voice Commands** in this guide.

PAIRING YOUR PHONE FOR THE FIRST TIME

Switch on *Bluetooth* on your device to begin pairing. To add a phone:

1. Select the phone  option on the feature bar.
2. Select **Add Phone**.
3. A prompt alerts you to search for the vehicle on your phone.
4. Select your vehicle on your phone.
5. Confirm that the number appearing on your phone matches the number on the touchscreen.
6. The touchscreen indicates when the pairing is successful.
7. Download the phonebook from your phone when you are prompted.

To pair subsequent phones, please see the **SYNC 3** chapter in your *Owner's Manual*.

USING YOUR CONNECTED PHONE

To make calls, select from your contacts, recent calls or dial the number on the phone keypad. From the phone menu, you can also adjust phone settings, change devices or mute your phone. The do not disturb mode rejects all incoming calls and switches off ring tones and alerts.

APPLE CARPLAY® AND ANDROID AUTO™*

Apple CarPlay and Android Auto are compatible with your system. To use Apple CarPlay and Android Auto, connect your device to a USB port and follow the instructions on the touchscreen. Certain SYNC 3 features are not available when you are using Apple CarPlay or Android Auto. Android Auto may need to be enabled from the settings menu. You can switch Apple CarPlay or Android Auto off through the settings menu. See the **SYNC 3** chapter of your *Owner's Manual* for more information.

AUDIO

You can select from a variety of entertainment options, including AM/FM radio, SiriusXM*, USB, *Bluetooth* Stereo and Apps.

PRESETS

To set a new preset, tune to the station and then press and hold one of the preset buttons. The audio mutes briefly while the system saves the station and then returns. To access additional presets, swipe left.

*if equipped




SYNC 3®*



CONNECTED VEHICLE

A connected vehicle has technology that allows your vehicle to connect to a mobile network and to access a range of features. When used in conjunction with the FordPass App, this technology could allow you to monitor and control your vehicle further, for example checking the tire pressures, the fuel level and the vehicle location. For additional information, refer to the local Ford website. The modem has a SIM. The modem was enabled when your vehicle was built and periodically sends messages to stay connected to the cell phone network, receive automatic software updates and send vehicle-related information to us, for example diagnostic information. These messages could include information that identifies your vehicle, the SIM and the electronic serial number of the modem. Cell phone network service providers could have access to additional information, for example cell phone network tower identification. For additional information about our privacy policy, visit www.FordConnected.com or refer to your local Ford website.

*if equipped



NAVIGATION

You can set your destination using the text entry or map screen. Using text entry, you can search by entering all or part of the destination, such as the address, intersection or city. Using the map screen, you can select a location on the map, then select **Start** to begin the route guidance. You can adjust the map to display in two-dimensional or three-dimensional mode. You can also zoom in or out on the map by using a pinching gesture. During route guidance, you will see a turn indicator, points of interest on the map, your current road and an option to mute the guidance prompts. You can press the button in the top left-hand corner of the main map to display estimated time of arrival, remaining travel time or distance to destination.

SETTINGS

Under the Settings menu, you can access and adjust the settings for many of the system features. Once you select a tile, press the **i** to view an explanation of the feature or setting.

APPS

The system allows you to interact with select mobile apps while keeping your eyes on the road. Voice commands, your steering wheel buttons or a quick tap on your touchscreen give you advanced control of compatible mobile apps. You can also stream your favorite music or podcasts, share your time of arrival with friends and keep connected safely. For more information on connecting apps to your system, please see the **SYNC 3** chapter of your **Owner's Manual**.

OFF ROAD

Before you venture off road, equip yourself with a clear mental picture of the underside of your vehicle. Learn the location of the fuel tank, engine sump and differentials. Learn the location

of any low hanging items and any skid plates that may be on the vehicle. You can avoid snagging them on rocks and other obstacles if you know where they are.

VEHICLE DIMENSIONS*

Approach Angle
30.4 degrees

Minimum Running Ground Clearance
8.8 in (223 mm)

Water Wading Depth
23.6 in (600 mm)

Departure Angle
33.1 degrees

Ramp Break Over Angle
20.4 degrees

*if equipped. Dimensions may vary, please see your Owners Manual for additional information.



OFF ROAD

DRIVING OFF ROAD

Off-road driving is driving your vehicle on unsurfaced roads or trails made from dirt, rocks, sand and mud. Before going off-roading, consult with your local governmental agencies to determine designated off-road trails and recreation areas. Also, be sure to understand any off-road vehicle registration requirements for the area in which you plan on driving. We recommend driving at least two vehicles while off-roading. The buddy system helps make sure that help is close at hand should a vehicle become stuck or damaged. We recommend taking supplies such as a first aid kit, supply of water, tow strap, cell or satellite phone any time you plan an off-road excursion.

DRIVING IN SNOW AND ICE

Your vehicle could slide while driving on snowy or icy roads. Turn the steering wheel in the direction of the slide until you regain control. Avoid sudden applications of power and quick changes of direction on snow and ice. Slowly and steadily apply the accelerator when starting from a full stop. Avoid sudden braking. Although a four-wheel drive vehicle may accelerate better than a two-wheel drive vehicle in snow and

ice, it cannot stop any faster as braking occurs at all four wheels. Make sure you allow sufficient distance between you and other vehicles for stopping. In emergency stopping situations, apply the brake pedal. Do not pump the brake pedal.

DRIVING IN SAND

When driving over sand, try to keep all four wheels on the most solid area of the trail. Drive through the terrain without varying vehicle speed. Apply the accelerator slowly and avoid excessive wheel slip. Avoid driving your vehicle in deep sand for an extended period of time as this may cause the system to overheat. Use the vehicle's momentum to maintain forward motion in sand. Avoid coming to a stop on steep sand slopes as the vehicle may not be able to continue forward motion after it has stopped.

DRIVING IN MUD

Be cautious of sudden changes in vehicle speed or direction when you are driving in mud, even four-wheel drive vehicles can lose traction in slick mud. If your vehicle does slide, steer in the direction of the slide until you regain control of your vehicle. After driving through mud, clean off residue stuck to rotating driveshafts and tires. Excess mud stuck on tires and rotating driveshafts can cause an imbalance that could damage drive components.

DRIVING OVER ROCKS AND GRAVEL

When approaching large rocks, position the vehicle so that the tires will pass over the largest obstacle. Never attempt to straddle a rock that is large enough to strike your axles or undercarriage, or drive over a rock which is large enough to contact the door sills. If you lose traction on your uphill wheels, stop immediately and choose a more suitable route.

Gravel is a constantly changing, low-grip surface. Driving at slow speeds on gravel reduces the risk of losing traction when you stop, accelerate or take a corner. Leave a generous gap between your vehicle and other vehicles, to minimize the risk of damage from flying gravel. Avoid dust clouds as they reduce visibility.

DRIVING THROUGH WATER

Determine the depth before attempting a water crossing. You should never stop or shut a vehicle off when crossing deep water unless you ingested water into the engine air intake. Slowly proceed and avoid splashing water any more than is necessary. Failure to follow the recommended speeds can result in vehicle damage. After driving through water and as soon as it is safe to do so, check the brakes, horn, lights and steering wheel to make sure everything is still in working order.



OFF ROAD

FOUR-WHEEL DRIVE

Note: Four-wheel drive is also called 4WD and 4x4.

This system has the ability to anticipate wheel slip and transfer torque to the front wheels before slip occurs. The system automatically turns on every time you switch the ignition on. A graphic is shown in the information display to advise you of the power distribution between the front and rear wheels. Four-wheel drive has operating characteristics that are somewhat different from two-wheel drive, both on and off the freeway. When driving at slow speeds under high-load conditions, use a low gear when possible. Depending on your vehicle, you can select a low gear through the gear shifter or by using the paddle shifters. Under severe operating conditions, the air conditioning may cycle on and off to prevent the engine from overheating. Drive slower in strong crosswinds as they can affect the normal steering characteristics of your vehicle. When driving your vehicle on surfaces made slippery by loose sand, water, gravel, snow or ice, proceed with care.

*if equipped

REAR DIFFERENTIAL LOCK*

The Rear Differential Lock is for off-road use only and is not for use on dry pavement. The rear differential lock provides additional traction should your vehicle become stuck. You can activate and deactivate the rear differential lock on the fly within the operating speed range. The rear differential lock automatically disengages when the vehicle speed exceeds a set value and it re-engages when the vehicle speed goes below a set value. Refer to the table in the *Drive Control* chapter of your *Owner's Manual* for the speeds when the rear differential lock activates and deactivates. It also engages based on selected drive modes.

The rear differential lock feature provides an indicator light in the information display when in use. While the feature is in standby mode, the light will display gray. While the feature is active, the light will become colored.

FOUR-WHEEL DRIVE LOCK

The four-wheel drive lock increases four-wheel drive performance by preventing the front and rear axles from disconnecting. You can activate and deactivate the four-wheel drive lock on the fly. It also engages based on certain selected drive modes. The four-wheel drive lock feature provides an indicator light in the information display when in use. While the feature is in standby mode, the light will display gray. While the feature is active, the light will become colored.

TRAIL CONTROL™

This feature lets you focus on steering during low-speed and off-road use by controlling your vehicle's acceleration and braking.

To use trail control, your speeds must be under:

- 20 mph (32 km/h) in all-wheel drive or four-wheel drive lock.
- 5 mph (8 km/h) in reverse (R).

Press the trail control button to switch the feature on and off. The system switches off if you exceed 42 mph (68 km/h). To set and adjust speed, use the SET+ and SET- buttons on the steering wheel. You can also adjust the set speed by braking.

Note: Pressing the brake pedal does not turn the system off. For more detailed information, please refer to your *Owner's Manual*.

TIRE PRESSURE MONITORING SYSTEM

The tire pressure monitoring system allows you to view the tire pressure readings through the information display. When one or more of your tires are under-inflated, your vehicle turns on the low tire pressure warning light in the instrument cluster. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the *Wheels and Tires* chapter of your *Owner's Manual* for more information.

TOWING POINTS*

Your vehicle comes equipped with fixed front recovery hooks. These hooks should never have a load applied to them greater than the gross vehicle weight rating of your vehicle. When recovering your vehicle, we recommend using both front hooks.

For more information about using the Towing Points, please see the *Roadside Emergencies* chapter of your *Owner's Manual*.



*if equipped



OFF ROAD

180 DEGREE CAMERA*

Provides a video image of the area in front of or behind your vehicle.

The system:

- Allows you to see what is directly in front of or behind your vehicle.
- Provides cross traffic view in front of your vehicle.
- Provides visibility during parking maneuvers. The camera button is on the audio unit.

Press the camera button to toggle between different views:

- Normal Rear View: Provides an image of what is directly behind your vehicle when your vehicle is in reverse (R).
- Expanded Rear View: Provides an expanded 180 degree image of what is directly behind your vehicle when your vehicle is in reverse (R).

- Normal Front View: Provides an image of what is directly in front of your vehicle when your vehicle is in park (P), neutral (N) or drive (D).
- Expanded Front View: Provides an expanded 180 degree image of what is directly in front of your vehicle when your vehicle is in park (P), neutral (N) or drive (D).








Note: The front view camera switches off if your vehicle speed exceeds 6 mph (10 km/h). You have to switch the system back on by using the camera system button once below the speed threshold. The front camera system switches on when you are in mud/ruts, rock crawl or sand mode and your speed is less than 15 mph (24 km/h). If you exceed 15 mph (24 km/h), the camera shuts off until your vehicle speed is below 13 mph (21 km/h). See the *Parking Aids* chapter of your *Owner's Manual* for details.

DRIVE MODE CONTROL

Goes Over Any-type of Terrain (G.O.A.T.) modes control delivers a driving experience through a suite of sophisticated electronic vehicle systems. The G.O.A.T. Drive Mode Control optimizes steering, handling and powertrain response. Changing the drive mode automatically changes the functionality of the electronically power-assisted steering system, the electronic stability control and traction control and the driveline settings. When using the drive modes, the electronic throttle control enhances the powertrain response and the engine sound changes based on each mode. The system automatically tailors your vehicle configuration for each mode you select on the console mounted controller.

Note: Mode changes are not available when the ignition is off.

Available modes may include:

-  Normal – For everyday driving.
-  Slippery – For use during inclement weather conditions.
-  Eco – For efficient driving.
-  Sport – For sporty driving with improved performance handling and response.
-  Sand – For off-road driving on soft, dry sand.
-  Rock Crawl* – For optimum rock-climbing ability.
-  Mud/Ruts* – For traversing muddy, rutted or uneven terrains.

Note: Your vehicle may only be equipped with some of the drive modes listed above.

For more information on drive control, please refer to the *Drive Mode Control* chapter in your *Owner's Manual*.

SELECTSHIFT AUTOMATIC™ TRANSMISSION*

With SelectShift automatic transmission, you can change gears using the paddle shifters.

Pull any paddle to switch the feature on while in drive (D) or manual (M).

To change gears:

- Push the toggle switch (+) to upshift.
- Push the toggle switch (–) to downshift.

For more information and system operation, please see the *Transmission* chapter of your *Owner's Manual*.



*if equipped




OUTDOOR ENABLERS

POWER POINTS

Your vehicle may come equipped with 12 V DC 240 W or 110 V AC 400 W power points. The 12 V power outlet can power devices using a 12 V outlet adapter. The 110 V outlet can power devices that use a household plug.

These power points may be in the following locations:

- A On the lower instrument panel.
- B Inside the center console.
- C On the rear of the center console.
- D In the cargo area.



STORAGE

REAR UNDER SEAT STORAGE*

Push the latch and lift the seat cushion to access the storage compartment.

UNDER FLOOR STORAGE

The luggage compartment load floor can be adjusted to lay flat or angled.

MAP POCKET

A zipper map pocket and strap system are located on the back of the front seats.



REAR FLOODLAMPS

Press the button on the left-hand side of the cargo area to switch the rear floodlamp on and off. The rear floodlamp turns off approximately 30 minutes after you switch it on. You can rotate the rear floodlamps to direct light closer or further away from the rear of the vehicle. The rear floodlamps will shut off after 45 minutes. After they have shut off twice you need to restart your vehicle to switch them back on.

ADJUSTING THE LUGGAGE COMPARTMENT DIVIDER*

You can place the divider in a variety of positions to accommodate your adventure.

FULL SHELF POSITION

Slide the luggage compartment divider onto the tracks on each side of the vehicle. Align the triangles on the divider with the triangles on the tracks and turn the latches to lock into place.

FOLDED SHELF POSITION

With the luggage compartment divider locked in the full shelf position, you can fold the luggage compartment divider in half. This is the recommended position to drive when shelf is empty to avoid noise.

TABLE POSITION

Slide the luggage compartment divider to the first locking position. Align the triangles on the divider with the triangles on the tracks and turn the latches to lock into place. Pull the table legs down and lock into place on the bumper.

DIVIDER POSITION

Fold the divider and insert it into the forward or rearward slots.

STORAGE POSITION

Store the luggage compartment divider behind the rear seat.



*if equipped



CONVENIENCE

DUAL AUTOMATIC TEMPERATURE CONTROL*

You and your front passenger can press independent controls to adjust the air temperature on each side of the vehicle. To return to one temperature, press the DUAL button. The passenger setting then switches to the driver-set temperature.

FOLDING THE REAR SEATS


With the seat empty, push the button on the top of the seat to fold the seat backrest forward. Fold the outermost head restraints and pull the center head restraint up to the first locked position. To unfold the seat backrest, pull the seat backrest up to unfold it. Please see the **Seats** chapter of the *Owner's Manual* for more information.




*if equipped

MOONROOF*

The moonroof controls are on the overhead console and have a one-touch open and close feature. To stop its movement during one-touch operation, press the control a second time.

 Press and release the rear of the control to open the moonroof. Press and release the front of the control to close the moonroof. When the glass is closed, press and release to vent the moonroof.

 Press and release the rear of the control to open the sunscreen. The sunscreen automatically opens with the moonroof. Press and release the front of the control to close the sunscreen.

TRAILER TOW*

Before you tow anything with your vehicle, refer to your *Owner's Manual* for complete information on weight, details and limitations, as well as safety information and the proper equipment to use while towing.

WIPER OPERATION

Adjust the wiper lever and its controls to operate the front and rear wipers.

- Single wipe: Pull the lever down.
- Intermittent wipe: Raise the lever upward to first position and then rotate the control:
 - Upward for short wipe intervals.
 - Downward for long wipe intervals.
- Normal wipe: Raise the lever upward to the second position.
- High-speed wipe: Raise the lever to the third position, its highest position.

FRONT AND REAR CAMERA WASHERS*

When you switch on the windshield or rear washer, the corresponding camera washer also turns on.

*if equipped



CONVENIENCE



SPEED DEPENDENT WIPERS

When your vehicle speed increases, the interval between wipes decreases.

REAR WINDOW WIPER AND WASHER


To operate the wiper, press the rocker switch on the end of the lever to change between off, intermittent and low speed.

Depending on your vehicle, when you switch on the front wipers and move the gearshift lever to reverse (R), the rear intermittent wiper may turn on.

To use the rear washer, push the wiper lever away from you. When you release the lever, the rear wiper operates for a short time.

LIFTGATE AND LIFTGATE WINDOW

On your remote entry transmitter, press **A** twice within a few seconds to open or close your liftgate. To open using the outside control button, unlock the liftgate with the remote control. Press **A** to open the glass. Press the liftgate release button **B** to open the liftgate. A handle is located inside the liftgate to help with closing.



*if equipped

PRE-COLLISION ASSIST*

If your vehicle is rapidly approaching a stationary vehicle, a vehicle traveling in the same direction as yours or a pedestrian within your driving path, the system is designed to provide three levels of functionality:

Alert: When active, a flashing visual warning displays and an audible warning tone sounds.

Brake Support: Assists the driver in reducing collision speed by preparing the brake system for rapid braking. Brake support does not automatically apply the brakes, but if the brake pedal is pressed even lightly by the driver, brake support could add additional braking up to full force.

Active Braking: Active braking may activate if the system determines that a collision is imminent. The system may help the driver reduce impact.

REAR PARKING AID*

The rear sensors are only active when the transmission is in reverse (R). As your vehicle moves closer to the obstacle, the rate of the audible warning increases. When the obstacle is less than 12 inches (30 centimeters) away, the warning sounds continuously. If the system detects a stationary or receding object farther than 12 inches (30 centimeters) from the corners of the bumper, the tone sounds for only three seconds. Once the system detects an object approaching, the warning sounds again. The coverage area is up to 6 feet (1.8 meters) from the rear bumper. There may be a decreased coverage area at the outer corners of the bumper.

SPEED SIGN RECOGNITION*

Speed sign recognition detects speed limit signs to inform you of the current speed limit. When the system detects a speed limit sign, the speed limit appears in the information display. To switch the feature on and off, use the touchscreen to select **Settings**, then **Driver Assistance**, then **Speed Sign Recognition**. From this screen you can also adjust the tolerance of the speed warning.



BLIS® (BLIND SPOT INFORMATION SYSTEM) AND CROSS TRAFFIC ALERT

BLIS helps you determine if a vehicle may be in your blind spot zone. Cross traffic alert warns you of vehicles approaching from the sides when the transmission is in reverse (R). Both systems turn on an indicator light in the exterior mirror on the side of the vehicle from which the approaching vehicle is coming. Cross traffic alert also sounds tones and displays messages to warn you from which direction vehicles are approaching.

Note: Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your *Owner's Manual* for safety information, more details and system limitations.



*if equipped



FUNCTION

REAR VIEW CAMERA

The rear view camera system provides a video image of the area behind the vehicle. The image appears when the transmission is in reverse (R) and uses a variety of guidelines to alert you of your proximity to objects. If your vehicle is equipped with the obstacle distance indicator, the system provides an image of your vehicle and the red, yellow and green sensor zones. For more information about the rear view camera, please see the **Parking Aids** chapter of your *Owner's Manual*.

Note: Switching on the rear washer also turns on the rear camera washer.

ELECTRIC PARKING BRAKE

The electric parking brake switch replaces the conventional hand brake. The switch is on the center console or to the left-hand side of the steering wheel, on the lower part of the instrument panel. To apply the electric parking brake, pull the switch up. The brake system warning lamp flashes, then illuminates, to confirm that you applied the parking brake. To release the electric parking brake manually, switch the ignition on, press the brake pedal and then press the switch down. The brake system warning lamp turns off. Your vehicle automatically releases the parking brake when the driver door is closed, the accelerator pedal is pressed and no faults are detected in the parking brake system.

Note: If the electric parking brake warning lamp stays on, then the electric parking brake did not automatically release. You must release the electric parking brake using the switch.

POST CRASH ALERT SYSTEM

The system flashes the direction indicators and sounds the horn (intermittently) in the event of a serious impact that deploys an airbag equipped on your vehicle.

The horn and lamps turn off when:

- You press the hazard control button.
- You press the panic button (🔊) on the remote entry transmitter*.
- Your vehicle runs out of power.

WIRELESS CHARGING*

This feature supports Qi wireless charging-compatible devices. You can only charge one device at a time on the charging area. You can charge a device if the vehicle is on, in accessory mode or if SYNC is on. To begin charging your device, place the device in the center of the charging surface with the charging side down. The charging stops after your device reaches a full charge. For more information, see the **Auxiliary Power Points** chapter of your *Owner's Manual*.

MYKEY™

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things such as speed restrictions and limited volume levels. For complete information, refer to the **MyKey** chapter in your *Owner's Manual*.



DRIVER ALERT

The system automatically monitors your driving behavior using various inputs, including the front camera sensor. If the system detects that driver alertness is below a certain threshold, the system alerts you using a tone and a message in the information display. The warning system is in two stages. At first, the system issues a temporary warning that you need to take a rest. This message will only appear for a short time. If the system detects further reduced driver alertness, the system issues another warning that remains in the information display for a longer time. Press **OK** on the steering wheel to clear the warning. You may switch the system on or off through the information display.

ROOF RACK

You must place loads directly on crossbars affixed to the roof rack side rails for the roof rack to correctly function. Make sure you never place loads directly on the roof panel. The roof panel is not designed to directly carry a load. When using the roof rack system, we recommend you use Ford Genuine Accessory crossbars designed specifically for your vehicle. Make sure that you securely fasten the load. Check the tightness of the load before driving and at each fuel stop. Please check the **Load Carrying** chapter of your *Owner's Manual* for maximum roof load amounts.

*if equipped

*if equipped



FUNCTION

LANE KEEPING SYSTEM*

When you switch the system on and the system detects an unintentional drift out of your lane is likely to occur, the system notifies or assists you to stay in your lane through the steering system and information display. Depending on the feature operation mode you select, the system provides a warning by vibrating the steering wheel (Alert Mode) or a steering assistance (Aid Mode) by gently counter steering your vehicle back into the lane. The system can also provide both warning (vibrating the steering wheel) and steering assistance (gently counter steering your vehicle back into the lane) while Aid+Alert mode is selected. You can switch the system on or off by pressing the button on the direction indicator. Refer to the *Driving Aids* chapter of your *Owner's Manual* for system operation and limitations.

SECURICODE™ KEYLESS ENTRY SYSTEM*

The SecuriCode keypad is near the driver window and illuminates when touched. The keypad allows you to lock or unlock the doors without a key. You can operate the keypad with the factory-set, five-digit entry code found on the owner's wallet card in the glove box or by using your personal code. You must press each number within five seconds of each other.

*if equipped

To Create a Personal Entry Code:

1. Enter the factory-set code.
2. Press **1-2** on the keypad within five seconds.
3. Enter your personal five-digit code. You must enter each number within five seconds of each other.
4. Press **1-2** on the keypad to save personal code 1. You may have up to 5 personal entry codes. The factory-set code will work even if you have set a personal entry code.

To Unlock the Driver Door

Enter the factory-set, five-digit code or your personal code. The interior lamps turn on.

To Unlock All Doors

Enter the factory-set code or your personal code, then press **3-4** within five seconds.

To Lock All Doors

Press and hold **7-8** and **9-0** at the same time (with the driver door closed). You do not need to enter the keypad code first.

See the *Doors and Locks* chapter in your *Owner's Manual* for more information on how to use SecuriCode.

ESSENTIAL FEATURES

FUEL TANK CAPACITY AND FUEL INFO

Your vehicle has a 16.0 gal (60.5 L) fuel tank capacity. We recommend regular unleaded gasoline with a pump (R+M)/2 octane rating of 87. To provide improved performance, we recommend premium fuel for severe-duty usage, such as trailer towing. Use only UNLEADED fuel or UNLEADED fuel blended with a maximum of 15% ethanol and a minimum octane rating of 87. Do not use any other fuel because it could damage or impair the emission control system.

REFUELING

When fueling your vehicle:

1. Make sure the ignition is switched off.
2. Press the lower rear corner of the fuel door to open.

3. Insert the fuel pump nozzle into the fuel system up to the first notch, and leave the nozzle inserted and resting on the cover of the fuel tank filler pipe opening.
4. Make sure you keep the fuel pump nozzle in a level position when refueling or it may impact the flow of the fuel. Improper positioning can also cause the fuel pump to shut off before the fuel tank is full.
5. When you finish refueling, slowly raise and remove the fuel pump nozzle. Fully close the fuel door.

If you are refilling your tank from a fuel container, make sure you use the fuel filler funnel included with your vehicle. Using an aftermarket funnel may not work with the capless system and could cause damage to your vehicle. For more information and for your fuel filler funnel location, please see the *Fuel and Refueling* chapter of your *Owner's Manual*.

TOWING YOUR VEHICLE

Towing your vehicle may be limited. Refer to the *Towing the Vehicle on Four Wheels* section in the *Towing* chapter of your *Owner's Manual*.

LOCATION OF SPARE TIRE AND TOOLS

Your spare tire and tools are under the carpeted wheel cover. A dissimilar spare tire is designed for emergency use only and should be replaced as soon as possible. For complete details on changing your tire, refer to the *Wheels and Tires* chapter of your *Owner's Manual*.

REAR WINDOW BUFFETING

You may hear a pulsing noise when just one of the windows is open. Lower the opposite window slightly to reduce this noise.

2021 BRONCO SPORT



PAGES
26
27

Ford Motor Company gives you peace of mind with the complimentary Roadside Assistance Program. Services are available from the warranty start date and last for 5 years or 60,000 miles (100,000 km), whichever occurs first.

Roadside Assistance is honored throughout the 50 states, Puerto Rico and Canada.

Towing services are available to any qualified Ford or Lincoln dealer within the distance limits stated in your Owner's Manual.

If you're out of warranty coverage but need Roadside Assistance, you can still access the service you need by paying a one-time fee.

For additional information please visit:

US:
<https://owner.ford.com/service/roadside-assistance.html>

Canada:
<https://www.ford.ca/owners/packages/roadside-assistance>



The Sykes4Ford Roadside App (Canada only) is available via the Apple App Store® or Google Play™.

U.S. ROADSIDE ASSISTANCE

1-800-241-3673

24 hours a day, 7 days a week

- Towing
- Battery Jump-Start
- Fuel Delivery
- Lock-out Assistance
- Flat Tire Change
- Winch Out
- Other Roadside Services



CANADA ROADSIDE ASSISTANCE

1-800-665-2006 or download

the Sykes4Ford App

- Towing
- Battery Boosting
- Fuel Delivery
- Lock-out Assistance
- Flat Tire Service
- Winch Out
- Other Roadside Services



For future quick reference, enter your vehicle information on the back of your Roadside Assistance Card and place it in your wallet.