


**VOICE RECOGNITION TIPS** (If equipped)

**BLUETOOTH®**


Command	Example
Dial <Phone #>	"Dial 7-1-4-9-6-5-3-0-0-0"
Call <Name>	"Call John Smith"

**Improving how you store your contacts can optimize your Bluetooth® Voice Recognition performance:**

- Use full names instead of short or single-syllable names ("John or Dad")
- Avoid using special characters/emojis or abbreviations ("Dr.") when saving contacts



UNLOCKING VEHICLE - page 01



- INTRODUCTION AND LOCATION OF THE SERVICE DEPARTMENT
- SET FIRST SERVICE APPOINTMENT
- REVIEW FACTORY RECOMMENDED MAINTENANCE SCHEDULE
- WAS THE CONDITION OF YOUR VEHICLE (AT DELIVERY) TO YOUR SATISFACTION?


Sales Consultant _____	Date _____	Sales Manager _____	Date _____
Customer _____		Date _____	
Email _____			

**MAINTENANCE**

Scheduled Maintenance	Normal Usage	Severe Usage*
Engine Oil and Filter	Replace 7,500 or 12 mos.	Replace 3,750 or 6 mos.
Fuel Additives *1	Add 7,500 or 12 mos.	Add Same as Normal
Tire Rotation	Perform 7,500	Perform 7,500
Air Cleaner Filter	Inspect 7,500 Replace 22,500	Inspect Same as Normal Replace More Frequently
Vacuum Hose	Inspect 7,500	Inspect Same as Normal
Climate Control Air Filter (for Evaporator and Blower Unit)	Replace 7,500 or 12 mos.	Replace More Frequently
Air Conditioning Refrigerant	Inspect 7,500	Inspect Same as Normal
Brake Hoses & Lines	Inspect 7,500	Inspect Same as Normal
Drive Shafts & Boots	Inspect 7,500	Inspect 3,750 or 6 mos.
Exhaust Pipe & Muffler	Inspect 7,500	Inspect Same as Normal
Front Brake Disc/Pads, Calipers	Inspect 7,500	Inspect More Frequently
Rear Brake Drum / Linings Rear Brake Disc / Pads	Inspect 7,500	Inspect More Frequently
Steering Gear Box, Linkage & Boots / Lower Arm Ball Joint, Upper Arm Ball Joint	Inspect 7,500	Inspect More Frequently
Suspension Mounting Bolts	Inspect 7,500	Inspect Same as Normal
Brake / Clutch Fluid	Inspect 15,000	Inspect Same as Normal
Crankcase Ventilation Hose	Inspect 15,000	Inspect Same as Normal
Fuel Filter	Inspect 15,000	Inspect Same as Normal
Fuel Lines, Fuel Hoses and Connections	Inspect 30,000	Inspect Same as Normal
Fuel Tank Air Filter	Inspect 15,000	Inspect Same as Normal
Parking Brake	Inspect 15,000	Replace More Frequently
Vapor Hose, Fuel Tank & Fuel Filler Cap	Inspect 15,000	Inspect Same as Normal
Spark Plugs	Replace 97,500	Replace More Frequently
Drive Belt (Alt, A / C)	1st Inspect 60,000 or 72 mos. Add'l Inspect 15,000 or 24 mos.	Inspect Same as Normal
Coolant	1st Inspect 120,000 or 120 mos. Add'l Replace 30,000 or 24 mos.	Replace Same as Normal
Manual Transmission Fluid	Inspect 30,000	Replace 75,000
Automatic Transmission Fluid	No checks, No services required	Replace 60,000

\*Check the engine oil regularly between recommended oil change. Hyundai recommends Quaker State oil.  
\*1 If TOP TIER Detergent Gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Hyundai dealer along with information on how to use them. Do not mix other additives.  
\*See Owner's Manual for details regarding Severe Usage maintenance recommendations.

Looking For more detailed information? This Quick Reference Guide does not replace your vehicle's Owner's Manual. If you require additional information or are unsure of a specific issue, We recommend that you always refer to the vehicle's Owner's Manual or contact your authorized Hyundai dealer. The information contained in this Quick Reference Guide is correct at the time of printing; however, specifications and equipment can change without notice. No warranty or guarantee is being extended in this Quick Reference Guide, and Hyundai reserves the right to change product specifications and equipment at any time without incurring obligations. Some vehicles are shown with optional equipment.



# The Hyundai ACCENT

Quick Reference Guide

Roadside Assistance: 1-800-243-7766  
 Consumer Affairs: 1-800-633-5151  
 Sirius XM® Radio: 1-800-967-2346  
 Blue Link: 1-855-2BLUELINK (1-855-225-8354)



## **HYUNDAI VEHICLE OWNER PRIVACY POLICY**

Your Hyundai vehicle may be equipped with technologies and services that use information collected, generated, recorded or stored by the vehicle. Hyundai has created a Vehicle Owner Privacy Policy to explain how these technologies and services collect, use, and share this information.

You may read our Vehicle Owner Privacy Policy on the Hyundaiusa.com website at <https://www.hyundaiusa.com/owner-privacy-policy.aspx>. If you would like to receive a hard copy of our Vehicle Owner Privacy Policy, please contact our Customer Connect Center at:

Hyundai Motor America  
Hyundai Customer Connect Center  
P.O. Box 20850  
Fountain Valley, CA 92728-0850  
800-633-5151 [consumeraffairs@hmausa.com](mailto:consumeraffairs@hmausa.com)


Hyundai's Customer Connect Center representatives are available Monday through Friday, between the hours of 5:00 AM and 7:00 PM PST and Saturday and Sunday between 6:30 AM and 3:00 PM PST (English). For Customer Connect Center assistance in Spanish or Korean, representatives are available Monday through Friday between 6:30 AM and 3:00 PM PST.




Headlights  
Page 04



Instrument  
Cluster  
Page 05



Cruise  
Control  
Page 22



Climate  
Control  
Page 09

## FEATURES AND CONTROLS

Climate Control	09
Display Mode Control	08
Display Modes	08
Headlights	04
Instrument Cluster	05
Instrument Panel Illumination	07
Remote & Smart Key	01
Seat-Front Seat Adjustment	02
Seat-Headrest Adjustment	02
Seat- Rear Seat Folding	02
Seat- Seat Belt Adjustment	03
Seat-Seat Warmer	03
Smart Trunk	03
Warnings and indicators	07

## MULTIMEDIA

Blue Link Telematics System	18
Bluetooth Phone Call Operational Tips	15
Bluetooth Phone Operation	13
Steering Wheel Audio Control	15
Voice Recognition Tips	17

## DRIVING

Cruise Control	22
Drive Mode Integrated Control System	22
Forward Collision-avoidance Assist (FCA)	21


### **WARNING!**

To reduce the risk of serious injury to yourself and others, read and understand the important SAFETY INFORMATION in your Owner's Manual.


Use this Quick Reference Guide to learn about the features that will enhance your enjoyment of your Hyundai. More detailed information about these features are available in your Owner's Manual.

\* Some vehicles may not be equipped with all the listed features.


## REMOTE & SMART KEY



- Lock
- Unlock
- Trunk Unlock
- Panic




**Removing the mechanical key**  
Slide and hold the release button **A** to remove the mechanical key.




**Driver's door Lock / Unlock**  
Smart key must be within 28–40in. from the outside door handle.  
**Press:** One time - Unlock driver door  
Two times - Unlock all doors  
Three times - Lock all doors

**NOTE:** User selectable option : Please see section 3 from Owner's Manual for more details.




To unfold the mechanical key, press the release button on the remote.


## FRONT SEAT ADJUSTMENT (Manual)



- 1 Forward and Backward
- 2 Seat Height
- 3 Seatback Angle





## HEADREST ADJUSTMENT




**To Raise the Headrest:**  
Pull the headrest up.

**To Lower the Headrest:**  
Press the lock button while pressing down on the headrest.


## REAR SEAT FOLDING



## SEAT WARMER (Front seat)




Each time you push the switch, the setting is changed as following:




Seat warmer will default to "Off" once ignition is cycled off.

## SEAT BELT ADJUSTMENT (Front seat)




Pull up to raise.



Press button and push down to lower.

## SMART TRUNK



### Smart Trunk

Trunk will open automatically when detecting smart key within the range near the trunk for over 3 seconds.

### To enable Smart Trunk function:


Vehicle must be in P (Park) to adjust the settings in the User Settings mode.

1. Select "Door" in the User Settings in the instrument cluster.
2. Check "Smart Trunk".


### NOTE:

Function is active after 15 seconds when all doors are closed and locked. The vehicle will also provide an audible and visual alarm while activating. Please refer to your Owner's Manual for further information.


## HEADLIGHTS



- ▶ | Headlight Position
- ▶ | Parking Light Position
- ▶ | **AUTO** Auto Light Position
- ▶ | **OFF** OFF Position



- ▶ | Headlight Position
- ▶ | Parking Light Position
- ▶ | **DRL** DRL Position
- ▶ | **OFF** OFF Position




- ▶ | Headlight Position
- ▶ | Parking Light Position
- ▶ | **AUTO** Auto Light Position
- ▶ | **DRL OFF** DRL OFF Position


### Headlight Delay

Headlights may stay on for 15 seconds after exiting and locking up the vehicle. Press the lock button on the remote key or smart key twice to turn off the headlights.

### Turn Signals and Lane Change Signals




### High Beam




### NOTE:

To turn off the high beam, pull the lever towards you.

### Flashing High Beam



### Fog light



Rotate switch up to turn on fog lights. Rotate switch down to turn off fog lights.

## INSTRUMENT CLUSTER

### Type A



- 1 Tachometer
- 2 Speedometer
- 3 Engine coolant temperature gauge
- 4 Fuel gauge
- 5 Warning and indicator lights
- 6 LCD display (including Trip computer)


### Type B



### WARNINGS AND INDICATORS

Air Bag Warning Light	Seat Belt Warning Light	Parking Brake & Brake Fluid Warning Light
Anti-Lock Brake System (ABS) Warning Light	Electronic Brake Force Distribution (EBD) System Warning Light	
Electric Power Steering (EPS) Warning Light	Malfunction Indicator Lamp (MIL)	Charging System Warning Light
Engine Oil Pressure Warning Light	Low Fuel Level Warning Light	Washer Fluid Warning Light
SPORT Mode Indicator	Master Warning Light	Electronic Stability Control (ESC) Indicator
Electronic Stability Control (ESC) OFF Indicator	Immobilizer Indicator	Turn Signal Indicator
High Beam Indicator	Light ON Indicator	Front Fog Indicator
Forward Collision-avoidance Assist (FCA) Warning light	CRUISE Cruise Indicator	SET Cruise SET Indicator
Low Tire Pressure Warning Indicator / TPMS Malfunction Lamp		

### INSTRUMENT PANEL ILLUMINATION




Press - or + to adjust the instrument cluster illumination brightness.




### DISPLAY MODES

Modes	Symbol	Description
Trip Computer		This mode displays driving information such as tripmeter, fuel economy, etc.
User Settings		In this mode, you can change settings of the doors, lamps, etc.
Warning		This mode displays warning messages related to the systems.

### DISPLAY MODE CONTROL




- TRIP:** MODE button for changing modes
- OK :** SELECT / RESET button for setting or resetting the selected item



## CLIMATE CONTROL

### Manual



- ① Temperature control knob
- ② Mode selection knob
- ③ Fan speed control knob
- ④ Air intake control button
- ⑤ Rear window defroster button
- ⑥ A/C (Air conditioning) button

### DEFOGGING / DEFROSTING



1. Select the defrost position.



2. Set the temperature control to the warmest setting.



3. Set the fan speed to the medium setting.

### AIR INTAKE CONTROL



Recirculated air position (LED on)



Outside (fresh) air position (LED off)


### MODE SELECTION



Changes the direction of the air flow as following:

- Face-Level
- Bi-Level
- Floor-Level
- Floor & Defrost-Level
- Defrost-Level

### REAR WINDOW DEFROSTER




Press to activate / deactivate the rear defroster.

### NOTE:

To reduce the tendency of the glass fogging and also to improve visibility, keep the interior surface of the windshield clean by wiping it with a clean cloth and glass cleaner. In addition, select air intake control to the outside (fresh) air position whenever possible while operating the vehicle.



## Automatic



- 1 Temperature control knob
- 2 Fan speed control knob
- 3 AUTO (automatic control) button
- 4 Air intake control button
- 5 OFF button
- 6 Front windshield defrost button
- 7 Rear window defrost button
- 8 Mode selection button
- 9 Air conditioning button
- 10 Climate control information screen

### DEFOGGING/DEFROSTING SYSTEM OFF




1. Press the front windshield defrost control button.



2. Set the temperature control to the warmest setting.



3. Set the fan speed to the medium setting.



Pressing the OFF button will place the system to the OFF mode.

- Climate control fan will turn off.
- Outside (fresh) air position will be selected.
- Vented air will be at last set temperature.

### AUTOMATIC HEATING / AIR CONDITIONING



The modes, fan speeds, air intake and air conditioning will be controlled automatically by the temperature setting you select.

### AIR INTAKE CONTROL




Recirculated air position (LED on)



Outside (fresh) air position (LED off)

### MODE SELECTION



Changes the direction of the air flow as following:




### NOTE:


To reduce the tendency of the glass fogging and also to improve visibility, keep the interior surface of the windshield clean by wiping it with a clean cloth and glass cleaner. In addition, select air intake control to the outside (fresh) air position whenever possible while operating the vehicle.

## BLUETOOTH PHONE OPERATION


### Phone setup (pairing phone) with Audio (Type A)



1. Press the PHONE button in the head unit or CALL button in the steering wheel remote control.



2. Search for the device name as displayed on your mobile phone and pair.




3. Confirm the 6-digit passkey displayed on the audio screen and the Bluetooth device are identical.

4. Press OK in your Bluetooth device.  
5. Pairing is complete.

**NOTE:** Vehicle must be parked to complete the pairing process.


### Phone setup (pairing phone) with Audio (Type B)



1. Press the PHONE button in the head unit or CALL button in the steering wheel remote control.
2. Pair your car after your mobile phone detects the Bluetooth device.
3. Enter the passkey or accept the authorization popup.
4. Connect Bluetooth.

**NOTE:** Vehicle must be parked to complete the pairing process.

## STEERING WHEEL AUDIO CONTROL




- 1 **MUTE**  
Mutes the audio.
- 2 **MODE**  
Changes the audio source.
- 3 **VOLUME (VOL + / -)**  
Increases or decreases the volume.
- 4 **SEEK / PRESET ( ^, v )**  
Changes the station.

## Bluetooth® PHONE CALL OPERATIONAL TIPS

In the following situations you or the other party may have difficulty hearing each other:

1. Keep the Bluetooth® volume to a low level. High level volume may result in distortion and echo.
2. When driving on a rough road, high speeds and / or with the window open.
3. When the air conditioning vents are facing the microphone and / or when the air conditioning fan is at the max speed.

### Steering wheel Bluetooth® control



- 1 **TALK**  
Activates voice recognition.
- 2 **CALL**  
Places and transfers calls.
- 3 **END**  
Ends calls or cancels functions.

### To Answer a Call:

- Press the  button on the steering wheel.

### To Reject a Call:


- Press the  button on the steering wheel.

### To Adjust Ring Volume:

- Use the VOLUME buttons on the steering wheel.

### To Transfer a Call to the Phone


#### (Private call on handset – do not use while driving):


- Press and hold the  button on the steering wheel until the audio system transfers a call to the phone.

### To Finish a Call:

- Press the  button on the steering wheel.


### Making a call using voice recognition:




Press  button on the steering wheel control to activate voice recognition.

Press and hold  button to end voice recognition.

### Calling by Name:

1. Press the  button.
2. Say the following command:
  - “Call <John Smith>”: Connects the call to John.
  - “Call <John Smith> on <on Mobile / at Work / at Home / on Other>”: Connects the call to John’s Mobile, Work, Home, or Other phone number.

### Dialing by Number:

1. Press the  button.
2. Say “Dial Number.”
3. Say the desired phone number.

For complete list of commands, refer to your Owner’s Manual.

## VOICE RECOGNITION TIPS (if equipped)

Your vehicle is equipped with Voice Recognition technology which allows drivers to operate their phones without having to take their eyes off the road to minimize distractions.


Voice recognition performance may be affected if driving with windows and sun roof open; when the heating-cooling system is on; when passing in a tunnel or when driving on rugged and uneven roads.

### Quick reference on using voice commands

To start voice command, press the  key, the following commands are available:

Command	Function
Call	Displays downloaded Contacts.
Call <Name>	Calls <Name> saved in Contacts.
Dial Number	Displays a screen where you can say a phone number to dial.
Dial <Phone #>	You can directly say the number to call. ex) Dial 111 555 1234
Redial	Directly calls at the number that you last dialed.
Call History	Displays your Call History.

## BLUE LINK TELEMATICS SYSTEM



Blue Link subscription is required. To enroll, please visit your dealership or MyHyundai.com.

Press the  button to access the voice-response menu of services.

- You can say:

- Service Link
- Roadside Assistance
- Account Assistance
- Help
- Cancel

Press the  button to launch Android Auto or Apple CarPlay if a supported device is connected.

Press the **SOS** button for SOS Emergency Assistance.

Visit HyundaiBlueLink.com for more information or refer to your Blue Link User's Manual for detailed information on system operation.

For immediate assistance with subscription services, please call 1-855-2BLUELINK (1-855-225-8354).

Google™ is a registered trademark of Google, Inc.

## Blue Link Mobile App



You can download the Blue Link mobile app to your compatible smart phone from the following sites:

- iPhone® — Apple® App Store
- Android™ — Google Play™

Visit [HyundaiBlueLink.com](http://HyundaiBlueLink.com) FAQs to see a list of compatible devices.



Scan to see list of compatible devices and to download the app.

## Remote Start

Remote Start enables you to remotely start your vehicle virtually from anywhere. For vehicles equipped with full-automatic temperature control, you can also enable climate control remotely and turn on the front window defroster, ensuring a warm or cool car is ready to go when you are.

- To use this feature, you must have a Blue Link Personal Identification Number (PIN). To create or change your PIN, log in to [www.MyHyundai.com](http://www.MyHyundai.com).

### Remember:

- Remote Start will automatically shut off after 10 minutes or after selected engine timer runs out in navigation vehicles.
- While this feature is active, the parking lights will blink until the vehicle is turned off or when vehicle is in operation.
- To continue to operate the vehicle, the proximity key must be inside the vehicle with the driver, prior to pressing the brake and being able to move the gearshift from the P (Park) position.

**NOTE:** Remote Start is not available on all models. Remote Start is only available for Push Start equipped vehicle with an Automatic Transmission. Remote Start with Climate Control additionally requires Fully Automatic Temperature Control.

### Preconditions:

- Ignition is OFF
- Alarm is armed (i.e., vehicle locked by key fob Remote Door Lock)
- Gearshift level is in the P (Park) position
- Brake pedal is not depressed
- Engine hood is securely closed
- All the doors are closed and locked
- The tailgate or trunk lid is closed
- The security / panic system is not activated
- The proximity key is not inside the vehicle
- The battery power is not low
- Vehicle is located in an open area
- It has been less than 4 days since last vehicle ignition off
- Vehicle located in area with good cell reception

### Remote Start will terminate:

- After 10 minutes or after selected engine timer runs out in navigation vehicles
- Brake is pressed without the proximity key inside the vehicle
- Alarm is triggered without the proximity key inside the vehicle
- Door / trunk is opened from inside the vehicle

**Notice:** Laws in some communities may restrict the use of the features that remotely start the engine. For example, some laws may require a person using the remote start feature to have the vehicle in view when doing so, or limit the length of time a vehicle engine may idle. Please check local and state regulations for any requirements and restrictions on remote starting of vehicles and engine idling time.


### WARNING!

Do not remote start vehicle in an enclosed environment (i.e., closed garage). Prolonged operation of a motor vehicle in an enclosed environment can cause a harmful build-up of carbon monoxide. Carbon monoxide is harmful to your health. Exposure to high levels of carbon monoxide can cause headaches, dizziness or in extreme cases unconsciousness and / or death. Do not leave children or animals unattended in a vehicle while using the remote start function.

### CAUTION!

If the vehicle's windshield wipers are left on when the vehicle was last driven, then the wipers will turn on if the remote start function is activated. To avoid damage to the wiper blades (i.e., due to heavy ice or snow accumulated on the windshield), please always turn the vehicle's windshield wipers off when parking the vehicle.

### FORWARD COLLISION-AVOIDANCE ASSIST (FCA) SYSTEM




The radar type Forward Collision-Avoidance Assist (FCA) system is to help reduce or to avoid accident risk. In certain circumstances, it recognizes the distance from the vehicle ahead through the sensors (i.e. radar), and, if necessary, warns the driver or applies emergency braking of accident risk with the warning message or the warning alarms.

**NOTE:**


Radar type FCA system does not operate for pedestrians in front.

To activate the system, select 'User Settings → Driving Assist → Forward Collision-Avoidance Assist (FCA)' The system deactivates, when the system setting is canceled.

The system will activate when the ESC (Electronic Stability Control) is on, and driving speed exceeds approximately 6 mph.



### DRIVE MODE INTEGRATED CONTROL SYSTEM



You can select the drive mode according to your preference or the road condition. The system resets to NORMAL mode when the engine is restarted.

Each time you press the button, the drive mode changes as following :



NORMAL mode is not displayed on the instrument cluster.

#### NORMAL mode

Normal mode provides regular daily driving performance with some fuel efficiency.


#### SPORT mode

Sport mode focuses on managing the driving dynamics by adjusting the steering effort along with the responsiveness of the engine and transmission.

#### Driving suggestions to improve fuel economy:

- Drive smoothly.
- Accelerate at moderate speed.
- Try to maintain your speed with traffic to prevent unnecessary speed adjustments.
- Always maintain a safe driving distance from the vehicle in front of you so you can avoid unnecessary braking.

### CRUISE CONTROL



The Cruise Control system allows you to program the vehicle to maintain a constant speed without depressing the accelerator pedal.

- 1 To turn On / Off the Cruise Control
- 2 To Resume or Increase the Cruise Control speed
- 3 To Set or Decrease the Cruise Control speed
- 4 To Cancel the Cruise Control

**NOTE:**

The system cancels automatically if vehicle speed is under 20mph. Depress the accelerator or brake pedal to actively adjust the vehicle speed, and the distance to the vehicle ahead.

### ACCENT CUSTOMER DELIVERY CHECK LIST

HYUNDAI OWNER	DEALERSHIP NAME
SALES CONSULTANT	DATE
VIN	PREVIOUS VEHICLE

### BEFORE DELIVERY

- SET TIRE PRESSURE LF\_\_RF\_\_RR\_\_LR\_\_
- VERIFY VEHICLE IS CLEAN, IN GOOD CONDITION, FREE OF CHIPS AND SCRATCHES · CLEAN WINDSHIELD AND BACK WINDOW
- ENSURE FLOORMATS ARE SNAPPED INTO PLACE

### WALK THE CUSTOMER THROUGH EACH OF THE FOLLOWING KEY DELIVERY FEATURES

- REVIEW QUICK REFERENCE GUIDE
- PAIR CUSTOMER'S PHONE TO THE BLUETOOTH SYSTEM
- REVIEW AND TEAR OFF VOICE COMMAND / QUICK TIP CARD
- HOW TO DEFROST - page 09
  - 1 Press the front defrost button
  - 2 Set to the warmest temperature setting
  - 3 Set to the highest fan speed

BLUETOOTH® HANDS-FREE HYUNDAI

#### CONNECTING YOUR PHONE

On the radio:

1. Push the **SETUP** button.
2. Select **Bluetooth**.
3. Select **Bluetooth Connection**.
4. Select **Add New**.

In your phone's **Bluetooth** settings:

5. Select the <Vehicle Name> on your phone.
6. Enter the passkey from the radio or accept the authorization pop-up on your phone.

#### SWITCHING BETWEEN PAIRED PHONES

Using Voice **Command**: "Change Bluetooth device"

On the radio:

1. Push the **SETUP** button.
2. Select **Bluetooth**.
3. Select **Bluetooth Connection**.
4. Select **Connect** next to the desired phone.

For more information, visit [HyundaiBluetooth.com](http://HyundaiBluetooth.com)